

## Subject: January 2016 Regular Update Details

### Common Function

#### G-scan2 Remote Control

G-scan2 can be remotely viewed and controlled by a PC (or an Android device) that is connected to the same WiFi network.

It will be more useful for remotely supporting the customers by allowing the tech support personnel to connect to the workshop PC with the remote access program like TeamViewer and then running VNC from the PC to connect to G-scan2.



Remote Control mode can be activated by pressing F2 and F5 keys together from the main menu.

VNC program for installation to the PC is not provided the customers who want to utilize this function need to download the freeware individually.

Separate instruction for VNC program installation and authentication setup on G-scan2 will be provided. Remote Control is not supported for G-scan1.

### TOYOTA/LEXUS

#### Active Sound Control System added

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test

#### Multi Bus Gateway System added

- Basic Function
- DTC analysis

#### Multi Bus Monitor1 System added

- Basic Function
- DTC analysis

#### Multi Bus Monitor2 System added

- Basic Function
- DTC analysis

#### Vehicle Proximity Notification System added

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test

#### Vehicle Control System added

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test

#### ARS(Active Rear Steer) System New Type added

- Basic Function
- DTC analysis
- Data analysis

#### Transmission(ECT/SMT/MMT) System New Type added

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test

#### Body4 System

- Basic Function added
- Data analysis
- Actuation Test

#### Body5 System

- Basic Function added
- Data analysis
- Actuation Test

#### TCCS system

- Basic Function improved
- Data analysis
- Advanced Function enhanced
- DPF Rejuvenate(PM)
- Catalyst record clear
- AT Learning Value Initialization
- Advanced Function added
- Engine Throttle Learning

#### Body System

- Communication stabilized
- Advanced Function enhanced
- Wireless Code Registration

#### Remote Engine Starter System

For more information, please email [sales@e-zds.com](mailto:sales@e-zds.com), or call +82-70-7733-7811 or 7775

- Communication stabilized

**Accessory Gateway System**

- Communication stabilized

**Tire Pressure Warning System**

- Communication stabilized

**Door Motor System**

- Communication stabilized

**ABS/VSC system**

- Advanced Function enhanced  
Accumulator 0 Down Drive

**AFS(Adaptive Front-Lighting System)**

- Advanced Function enhanced  
Vehicle Height Sensor Initialization

**Gateway System**

- Advanced Function Bug fixed  
Vehicle Height Sensor Initialization

**HONDA/ACURA****New System added****Acoustic Vehicle Alerting System**

- Basic Function  
DTC analysis  
Data Analysis  
ECU Information Display

**Electric Servo Brake System**

- Basic Function  
DTC analysis  
Data Analysis  
ECU Information Display

**BODY – Power Sliding Door**

- Basic Function  
DTC analysis  
Data Analysis  
Actuation Test

**New Type added****AT/CVT (DCT)**

- Basic Function  
DTC analysis  
Data Analysis  
ECU Information Display

**PCU**

- Basic Function  
DTC analysis  
Data Analysis  
ECU Information Display
- Advanced Function  
Self Check  
History Data

**BODY – Lighting**

- Basic Function  
DTC analysis  
Data analysis  
Actuation Test

**BODY – Keyless**

- Basic Function  
DTC analysis  
Data analysis  
Actuation Test
- Advanced Function  
Keyless Check

**BODY – Security**

- Basic Function  
DTC analysis  
Data analysis
- Advanced Function  
History Data  
History Data Clear

**BODY – Wiper**

- Basic Function  
DTC analysis  
Data analysis  
Actuation Test

**BODY – Doorlock**

- Basic Function  
DTC analysis  
Data analysis  
Actuation Test

**BODY – HVAC**

- Basic Function  
DTC analysis  
Data analysis
- Advanced Function  
HVAC Climate Control Unit Self Test

**Function Improved****ABS/VSA**

- COMM. Improved

**EPS**

- Basic Function

Data Analysis extended

**ABS/VSA**

- Basic Function
- Data Analysis extended

**Bug Fixed****Engine**

- Advanced Function
- IACV Test fixed

**AT/CVT**

- Advanced Function
- Clutch Pressure Control (Linear) Solenoid Valve A
- Test fixed
- Clutch Pressure Control (Linear) Solenoid Valve B
- Test fixed
- Clutch Pressure Control (Linear) Solenoid Valve C
- Test fixed

**ABS**

- Basic Function
- Data Analysis fixed

**SRS**

- Basic Function
- DTC Analysis fixed

**PCU**

- Basic Function
- Data Analysis fixed

**IMMO**

- Advanced Function
- Number of Keys fixed

**SHAWD**

- Advanced Function
- Shift Solenoid Test fixed
- Clutch Coil Test fixed

**Gauge**

- Basic Function
- Data Analysis fixed

**TPMS**

- Basic Function
- Erase fixed

- Oil Light Reset / Service Light Reset
- Throttle Body Learning

**CX-3 1.5L S5 Vehicle Added**

- PCM(Powertrain Control Module)
- TCM(Transmission Control Module)
- 4x4(4x4 Control Module)
- ABS(Anti-Lock Brake System)
- AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)
- EATC(Electronic Automatic Temperature Control)
- EPS(Electronic-Controlled Power Steering)
- ESU(Electric Supply Unit)
- IC(Instrument Cluster)
- RCM(Restraint Control Module)
- BSM(Blind Spot Monitoring)
- BCM(Body Control Module)
- CMU(Connectivity Master Unit)
- FSC(Forward Sensing Camera)
- SSU(Smart Start Unit)
- SCBS(Smart City Brake Support)
- SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)

**CX-3 2.0L PE Vehicle Added**

- PCM(Powertrain Control Module)
- TCM(Transmission Control Module)
- 4x4(4x4 Control Module)
- ABS(Anti-Lock Brake System)
- AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)
- EATC(Electronic Automatic Temperature Control)
- EPS(Electronic-Controlled Power Steering)
- ESU(Electric Supply Unit)
- IC(Instrument Cluster)
- RCM(Restraint Control Module)
- BSM(Blind Spot Monitoring)
- BCM(Body Control Module)
- CMU(Connectivity Master Unit)
- FSC(Forward Sensing Camera)
- SSU(Smart Start Unit)
- SCBS(Smart City Brake Support)
- SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)

**CX-5 2.0L PE System Added**

- BSM(Blind Spot Monitoring)

**CX-5 2.2L SH System Added**

- BSM(Blind Spot Monitoring)

**CX-5 2.5L PY System Added**

- BSM(Blind Spot Monitoring)

**AXELA/MAZDA3 2.5L PY System Added****MAZDA****Service Manual Added**

For more information, please email [sales@e-zds.com](mailto:sales@e-zds.com), or call +82-70-7733-7811 or 7775

- BSML(Blind Spot Monitoring Left)
- BSMR(Blind Spot Monitoring Right)

Reset

**MPV/MAZDA8 2.3L L3\_T Vehicle Added**

- PCM(Powertrain Control Module)
- ABS(Anti-Lock Brake System)
- AM(Amplifier Module)
- GEM(Generic Electronic Module)
- HCM(Headlamp Control Module)
- ICCM(Intelligent Cruise Control Module)-Beta Test
- IC(Instrument Cluster)
- LTM(Liftgate/Trunk Module)-Beta Test
- RCM(Restraint Control Module)
- RKE(Remote Keyless Entry)
- TCM(Transmission Control Module)
- LCM(Lighting Control Module)-Beta Test
- 4x4(4x4 Control Module)
- LPSDM(Left Power Sliding Door Module)
- RPSDM(Right Power Sliding Door Module)

## MITSUBISHI

**Feedback (Norway)**
**TPMS added**

- Advanced Function
  - Tire Pressure Sensor ID Registration
  - Tire Pressure Sensor ID Check

**Feedback (Taiwan)**
**MPI / GDI / DIESEL**

- 142B Check code added

**Feedback (Israel)**
**ELC-AT / CVT / TC-SST**

- Learned value reset bug fixed

**Feedback (Poland)**
**L200**

- DTC clear function bug fixed

**Feedback (Japan)**
**EK-WAGON**
**CVT added**

- Basic Function
  - DTC analysis
  - Data analysis
  - Actuation test
  - ECU Information
- Advanced Function
  - CVT Oil Degradation level
  - Sensor calibration
  - Electronic oil pump air bleeding

## NISSAN/INFINITI

**ENGINE New Type added (KWP, CAN)**

- Advanced Function
  - EVAP system close
- Tested on QUEST

**ENGINE New Type added (CAN)**

- Advanced Function
  - VIN Registration
- Tested on NOTE

**ANC(Active Noise Control) New System added (CAN)**

- Basic Function
  - DTC analysis
  - Data analysis
  - ECU information
  - Actuation Test
- Advanced Function
  - ANC SETTING
  - ASC SETTING
- Tested on SKYLINE HYBRIDE

**DAST 1(Directive Adaptive Steering) New System added (CAN)**

- Basic Function
  - DTC analysis
  - Data analysis
  - ECU information
- Tested on SKYLINE HYBRIDE

**DAST 2(Directive Adaptive Steering) New System added (CAN)**

- Basic Function
  - DTC analysis
  - Data analysis
  - ECU information
- Tested on: SKYLINE HYBRIDE

**Side Radar Left New System added (CAN)**

- Basic Function
  - DTC analysis
  - Data analysis
  - ECU information
  - Actuation Test
- Tested on: QUEST

**Side Radar Right New System added (CAN)**

- Basic Function
  - DTC analysis

 For more information, please email [sales@e-zds.com](mailto:sales@e-zds.com), or call +82-70-7733-7811 or 7775

Data analysis  
ECU information  
Actuation Test  
Tested on QUEST

- Received from USA: Side Radar Left, Side Radar  
Right systems added

**EV/HEV New Type added (CAN)**

- Basic Function  
DTC analysis  
ECU information  
Tested on FUGA HYBRIDE

**DAIHATSU****System Search function enhanced**

International > SYSTEM SEARCH

**HV BATTERY New Type added (CAN)**

- Basic Function  
DTC analysis  
Data analysis  
ECU information  
Tested on Leaf

**Steering Angle Sensor System added**

- Basic Function  
Data Analysis

**ICC(Intelligent Cruise Control New Type added (CAN)**

- Basic Function  
DTC analysis  
Data analysis  
ECU information  
Actuation Test  
- Advanced Function  
FEB default setting  
Tested on NOTE

**Body System added**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information Display

**Auto Levelling System added**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information Display

**TELEMATIC New Type added (CAN)**

- Advanced Function  
VIN Registration  
Tested on Leaf

**PCB System added**

- Basic Function  
DTC Analysis  
Data Analysis  
ECU Information Display

**LANE CAMERA New Type added (CAN)**

- Advanced Function  
Auto AIM  
AIM Check  
Tested on NOTE

**Sonar System added**

- Basic Function  
DTC Analysis  
Data Analysis  
ECU Information Display

**METER New Type added (CAN)**

- Advanced Function  
Outside Air Temperature Diagnosis  
Fuel meter diagnosis(analog pointer)  
Warning lamp diagnosis  
Tested on NOTE

**PSD(Power Sliding Door-Right) System added**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information Display

**Charger New Type added (CAN)**

- Advanced Function  
Charge current limitation history  
Tested on Leaf

**PSD(Power Sliding Door-Left) System added**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information Display

**Feedback**

- Received from Japan: ANC, DAST1, DAST2,  
EV/HEV(HYBRIDE) systems added

**Combi Switch System added**

- Basic Function
- Data Analysis
- ECU Information Display

**ITC(Intergrated Timer Control)**

- Basic Function Added
- ECU Information Display

**KFS(Key Free System)**

- Basic Function Added
- ECU Information Display

**SUBARU****Eye sight System added**

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information

**Engine control module – Gasoline New Type added**

- Basic Function
- Data Analysis

**Bug fixed****TPM(Tire pressure monitor)**

- Stabilized

**ODS(Occupant detection system)**

- Stabilized

**ISUZU****New D-MAX 4HK1 – TC New Type added**

- Basic Function
- Data Analysis
- Advanced Function
- DPD Forced regeneration
- DPD Slow regeneration
- DPD Automatic regeneration
- DPD Automatic regeneration reset
- DPD Regeneration data reset

**New D-MAX 4JJ1 – TC New Type added**

- Basic Function
- Data Analysis

**New D-MAX Auto transmission New Type added**

- Basic Function
- Data Analysis

**New D-MAX Auto transmission New Type added**

- Basic Function
- Data Analysis

**New D-MAX ABS New Type added**

- Basic Function
- Data Analysis

**New D-MAX Body control module New Type added**

- Basic Function
- Data Analysis

**New D-MAX Airbag New Type added**

- Basic Function
- Data Analysis

**New D-MAX Transfer case New Type added**

- Basic Function
- Data Analysis

**Bug fixed****Pickup truck : Anti lock brake system**

- Stabilized

**SSANGYONG****IMMOBILIZER Bug fixed****MUSSO IMMOBILIZER**

- Advanced Function
- Finger Data
- Key Coding

**HOLDEN****Bug fixed****Barina : Engine control unit**

- Bug fixed

**Jackaroo/Rodeo : Anti lock brake system**

- Stabilized

**FORD AU****New Model added****FGX Falcon**

PCM(PowerTrain Control Module)

TCM(Transmission Control Module)

ABS(Anti-Lock Brake System)  
RCM(Restraint Control Module)  
BEM(Body Electronic Module)  
IC(Instrument Cluster)  
HIM(HVAC Integrated Module)  
FCIM(Front Controls Interface Module)  
APIM(Accessory Protocol Interface Module)  
GPSM(Global Positioning System Module)  
GWM(Gateway Module A)  
PAM(Park Aid Module)  
ACM(Audio Control Module)

**SZ II Territory**

PCM(PowerTrain Control Module)  
TCM(Transmission Control Module)  
ABS(Anti-Lock Brake System)  
ACM(Audio Control Module)  
APIM(Accessory Protocol Interface Module)  
BEM(Body Electronic Module)  
FCIM(Front Controls Interface Module)  
GPSM(Global Positioning System Module)  
GWM(Gateway Module A)  
HIM(HVAC Integrated Module)  
IPC(Instrument Panel Control Module)  
PAM(Park Aid Module)  
PSCM(Power Steering Control Module)  
RCM(Restraint Control Module)

**SUZUKI/MARUTI****New System added****Auxiliary Power Module**

- Basic Function
  - DTC analysis
  - Data Analysis
  - ECU Information Display

**New Type added****Swift****EPI**

- Basic Function
  - DTC analysis
  - Data Analysis
  - Actuation Test
  - ECU Information Display

**Function Improved****ABS**

- Basic Function
  - Actuation Test

**Grand Vitara 2.0 TD**

- Comm. Improved

**Bug Fixed****Wagon R**

- Basic Function
  - Data Analysis fixed

**ABS**

- Advanced Function
  - Hydraulic Test fixed

**Immo**

- Advanced Function
  - ECM Change fixed

- Advanced Function
  - Key fixed

**TATA****Bug Fixed****MANZA****ABS**

- Basic Function
  - DTC Analysis fixed

**MERCEDES BENZ****New System added****ME/CDI/CNG - Engine control unit**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- Data Analysis
- Actuation Test
- ECU Information Display

**ESM - Electronic selector module**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- ECU Information Display

**VECU - Power monitoring control unit**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- ECU Information Display

**Hydrogen tank control unit**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- ECU Information Display

**High-temperature coolant pump control unit**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- ECU Information Display

**Fuel cell control unit**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- ECU Information Display

**Electric drive control unit**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- ECU Information Display

**DTR - Distronic**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- Data Analysis
- ECU Information Display

**BSA - Belt-driven starter/alternator**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- ECU Information Display

**ACS - Automatic clutch system**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- ECU Information Display

**ABS/ESP - Electronic stability program**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- Data Analysis
- Actuation Test
- ECU Information Display

**ES - Electrical power steering**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- Data Analysis
- ECU Information Display

**VP - Vacuum pump brake booster**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- ECU Information Display

**WSS - Weight sensing system**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- ECU Information Display

**SG-DDW - DC/DC converter control unit**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- ECU Information Display

**SAM-F/SAM-D - Signal acquisition and actuation module front/driver side**

- Basic Function
- DTC Analysis
- DTC Erase Memory
- ECU Information Display

**OCP - Overhead control panel**

- Basic Function



DTC Analysis  
DTC Erase Memory  
ECU Information Display

**Multifunction control unit**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
ECU Information Display

**LCP/HBF - Lower/Rear control panel**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
ECU Information Display

**KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
Data Analysis  
Actuation Test  
ECU Information Display

**EZS/EIS - Electronic ignition lock**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
ECU Information Display

**CGW - Central gateway**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
ECU Information Display

**BNS/BMS - Battery sensor**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
ECU Information Display

**ATA - ATA [EDW]/tow-away/interior protection**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
ECU Information Display

**TV - TV tuner**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
Data Analysis  
ECU Information Display

**RFK - Backup camera**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
Data Analysis  
ECU Information Display  
- Advanced Function  
Backup camera calibration  
Steering angle sensor calibration  
Calibration reset

**PTS - Parktronic system**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
ECU Information Display

**IC - Instrument cluster**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
Data Analysis  
Actuation Test  
ECU Information Display

**COU [ZBE] - Audio/COMAND operating unit**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
Data Analysis  
Actuation Test  
ECU Information Display

**ASSYST PLUS - PLUS Active Service System**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
Data Analysis  
ECU Information Display

**APS - Auto pilot system**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
ECU Information Display

**DCM-RR - Door control module rear right**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
ECU Information Display

**DCM-RL - Door control module rear left**

- Basic Function

DTC Analysis  
DTC Erase Memory  
ECU Information Display

**DCM-FR - Door control module front right**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
ECU Information Display

**DCM-FL - Door control module front left**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
ECU Information Display

**TSTH/STH - Stationary heater with remote control**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
ECU Information Display

**AAC - Automatic air conditioning**

- Basic Function  
DTC Analysis  
DTC Erase Memory  
Actuation Test  
ECU Information Display

**New Function added****ME/CDI/CNG - Engine control unit**

- Basic Function  
Actuation Test  
- Advanced Function  
Injector injection quantity adjustment  
Correction programming of the electric suction fan  
for engine or air conditioning  
Correction programming of fuel quantity  
Correction programming of idling specified speed  
Compression test  
Learning of fuel pump  
Learning of the throttle valve stop  
Performing sensor rotor adaptation  
Resetting of mixture adaptation  
Correction programming of ignition

**ABS/ESP - Electronic stability program**

- Basic Function  
Data Analysis  
Actuation Test  
- Advanced Function  
Standstill test  
Tire pressure loss warner (Activating)  
Road test  
Learning process

Resetting of variant locking  
Program brake assist

**Suspension**

- Basic Function  
Data Analysis  
- Advanced Function  
Level calibration  
Pneumatic tests  
Leakage tests  
Cyclically alternating actuation  
Calibration of the plunger travel sensors  
Load adjustment

**AB - Airbag**

- Basic Function  
Data Analysis

**IC - Instrument cluster**

- Basic Function  
Data Analysis  
Actuation Test  
- Advanced Function  
National version factor  
Warning threshold in days  
Distance driven since last oil change  
Days since last oil change  
Oil minimum warning  
Confirmation of general maintenance  
Advance odometer  
Reset odometer to 0 km  
Oil change  
Service work of last service  
Enter time with battery disconnected  
Set oil minimum warning  
National setting  
Day since last oil change

**ASSYST Active Service System**

- Basic Function  
Data Analysis

**Bug fixed**

ME/CDI/CNG - Engine control unit  
Suspension  
SBC - Sensotronic Brake Control  
HS/AIRSCARF - Seat heater/Air scarf system  
ES - Electrical power steering  
UCP - Upper control panel  
SCM [MRM] - Steering column module  
SAM-F/SAM-D - Signal acquisition and actuation  
module front/driver side  
RevETR-RF - Right front reversible emergency  
tensioning retractor  
RevETR-LF - Left front reversible emergency tensioning

retractor  
 OCP - Overhead control panel  
 Headlamp/Headlamp-L - Headlamp control unit  
 ATA - ATA [EDW]/tow-away/interior protection  
 AB - Airbag  
 TV - TV tuner  
 SOUND - Sound system  
 RFK - Backup camera  
 NBR-RR/IRS-HRA - Right rear range radar  
 NBR-RF - Right front range radar  
 NBR-LR/IRS-HLA - Left rear range radar  
 NBR-LF - Left front range radar  
 IC - Instrument cluster  
 ASSYST Active Service System  
 DCM-RR - Door control module rear right  
 DCM-RL - Door control module rear left  
 TSTH/STH - Stationary heater with remote control  
 AAC - Automatic air conditioning

### Stabilized

HS/AIRSCARF - Seat heater/Air scarf system  
 WSS - Weight sensing system  
 UCP - Upper control panel  
 SG-DDW - DC/DC converter control unit  
 SG-AWF - Collision prevention assist  
 SCM [MRM] - Steering column module  
 SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor  
 SAM-P - Passenger-side signal acquisition and actuation module  
 SAM-F/SAM-D - Signal acquisition and actuation module front/driver side  
 RevETR-RF - Right front reversible emergency tensioning retractor  
 RevETR-LF - Left front reversible emergency tensioning retractor  
 RCM - Rear control module  
 OCP - Overhead control panel  
 Multifunction control unit  
 LCP/HBF - Lower/Rear control panel  
 LAE [LAA] - Loading floor automatically extendable  
 KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking  
 HSW/LRH - Steering wheel heater  
 Headlamp-R - Headlamp control unit  
 Headlamp/Headlamp-L - Headlamp control unit  
 EZS/EIS - Electronic ignition lock  
 CGW - Central gateway  
 BNS/BMS - Battery sensor  
 ATA - ATA [EDW]/tow-away/interior protection  
 AHE - Trailer recognition  
 AB - Airbag  
 ZAN - Audio/COMAND display  
 VCS - Voice control  
 TV - TV tuner

Tuner - Standard tuner  
 Sound generator for exhaust system  
 SOUND - Sound system  
 SGR - Radar sensors control unit  
 360° - Camera  
 MFK - Multifunction camera  
 RFK - Backup camera  
 PTS - Parktronic system  
 NSA - Night View Assist  
 NBR-RR/IRS-HRA - Right rear range radar  
 NAV - Navigation module  
 MIF/UCI - Media interface  
 ICI - InCar Internet  
 IC - Instrument cluster  
 DVD player  
 DTA - Mbrace or TELEAID/GPS Box  
 D-FOR - Display in right rear passenger  
 D-FOL - Display in left rear passenger  
 DAB/SDAR - Digital/Satellite radio  
 CTEL/TEL - Cellular/Mobile telephone  
 COU [ZBE] - Audio/COMAND operating unit  
 CM - Compass module  
 AVE-H - Rear audio video unit  
 AUDIO/COMAND  
 ASSYST PLUS - PLUS Active Service System  
 ASSYST Active Service System  
 AMG Performance Media  
 AGW - Audio gateway  
 TSG-MR - Right center door control unit  
 TSG-ML - Left center door control unit  
 TLC/GTO - Garage door opener  
 RVC/VDS - Convertible roof control  
 REDC/RWT - Rear end door control module  
 PSD/MS - Sliding roof control  
 MKL-HR - Rear right multicontour backrest  
 MKL-HL - Rear left multicontour backrest  
 HS - Seat heater  
 HKS - Tailgate control  
 ESA-R - Electric seat adjustment rear  
 ESA Front passenger - Electric seat adjustment Front passenger  
 ESA Driver - Electric seat adjustment Driver  
 ERA - Electric fold down backrest system  
 DS-RF/AMKS-RF - Dynamic/Active seat  
 DSP/PPAMKS - Pneumatic pump for seat  
 DS-LF/AMKS-LF - Dynamic/Active seat  
 DCM-RR - Door control module rear right  
 DCM-RL - Door control module rear left  
 DCM-FR - Door control module front right  
 DCM-FL - Door control module front left  
 TSTH/STH - Stationary heater with remote control  
 KBE-H/REAR AC - Rear air conditioning  
 HBF - Rear control panel  
 EKMK - Electric refrigerant compressor  
 AAC - Automatic air conditioning

**BMW****F07 / F10 / F11 / F18 (2010 - present)****EHC (Electronic Ride-Height Control) added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**HU-H added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**STML (Headlight driver module, left) added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**STMR (Headlight driver module, right) added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**LHML (LED main light module, left) added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**LHMR (LED main light module, right) added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**TBX (Touchbox) added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**F06 / F12 / F13 (2011 - present) added****CAS (Car Access System)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**DME (Digital Engine Electronics)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**EGS (Electronic transmission management)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**EKPS (Electronic fuel-pump control)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**GWS (Gear selector switch)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**AL (Active steering)**

- Basic Function
- DTC analysis
- Data analysis
- ECU Information

**DSC (Dynamic stability control)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**EDCSVL (Damper satellite, front left)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**EDCSVR (Damper satellite, front right)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**EDCSHL (Damper satellite, rear left)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**EDCSHR (Damper satellite, rear right)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**EMF (Parking brake)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**EPS (Electromechanical power steering)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**HSR (Rear-axle slip-angle control)**

- Basic Function
- DTC analysis
- Data analysis
- ECU Information

**ICM (Integrated Chassis Management)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**VDM (Vertical Dynamics Management)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**ACSM (Crash Safety Module)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**AMPT (Top Hi-Fi amplifier)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**CBX-MEDIA (Combox Multimedia)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**CIC (Car Information Computer)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**CID (Central Information Display)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**CON (Controller)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**CVM (Convertible-top module)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**FRM (Footwell module)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**HUD (Head-Up Display)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**IHKA (Integrated automatic heating / air conditioning system)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**KAFAS (Camera-based driver-assistance systems)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**KOMBI (Instrument cluster)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**PDC (Park Distance Control)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**SMFA (Seat module, driver)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**SMBF (Seat module, passenger)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**SWW (Lane change warning)**

- Basic Function
- DTC analysis
- Data analysis

- Actuation test
- ECU Information

**SZL (Switch center, steering column)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**TRVC (ALL round-view camera)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

**ZGM (Central Gateway Module)**

- Basic Function
- DTC analysis
- Data analysis
- Actuation test
- ECU Information

## AUDI/VW/SEAT/SKODA

**UDS Type Tire Pressure System added**

- Basic Function
  - DTC analysis
  - Data analysis
  - Actuation Test
  - ECU Information Display
- Advanced Function
  - Basic setting
  - Adaptation
  - Coding
  - Security Access

**UDS Type Trailer System added**

- Basic Function
  - DTC analysis
  - Data analysis
  - Actuation Test
  - ECU Information Display
- Advanced Function
  - Basic setting
  - Adaptation
  - Coding
  - Security Access

**UDS Type Trunk Elect System added**

- Basic Function
  - DTC analysis

- Data analysis
- Actuation Test
- ECU Information Display
- Advanced Function
- Basic setting
- Coding
- Security Access

**UDS Type Hybrid Battery System added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU Information Display
- Advanced Function
- Basic setting
- Adaptation
- Coding
- Security Access

**UDS Type Struct. Borne Sound System added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU Information Display
- Advanced Function
- Basic setting
- Coding
- Security Access

**UDS Type Engine Electronics New Type Added**

- Basic Function
- Data analysis
- Actuation Test
- ECU Information Display
- Advanced Function
- Basic setting
- Adaptation
- Coding

**UDS Type Transmission Electronics New Type Added**

- Basic Function
- Data analysis
- Actuation Test
- ECU Information Display
- Advanced Function
- Basic setting
- Coding

**UDS Type Brake Electronics New Type Added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test

- ECU Information Display
- Advanced Function
- Adaptation
- Basic setting
- Coding

**UDS Type Auto HVAC New Type Added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU Information Display
- Advanced Function
- Basic setting
- Coding

**UDS Type Electronic Central Electrics New Type Added**

- Basic Function
- Data analysis
- Actuation Test
- ECU Information Display
- Advanced Function
- Basic setting

**UDS Type Airbag New Type Added**

- Basic Function
- Data analysis
- Actuation Test
- ECU Information Display
- Advanced Function
- Adaptation

**UDS Type CAN Gateway New Type Added**

- Basic Function
- Data analysis
- Actuation Test
- ECU Information Display
- Advanced Function
- Basic setting

**UDS Type Headlight Range Control New Type Added**

- Advanced Function
- Coding
- Security Access

**UDS Type Steering Assistance New Type Added**

- Basic Function
- Data analysis
- Actuation Test
- ECU Information Display
- Advanced Function
- Basic setting
- Coding
- Security Access

### UDS Type Instrument Cluster System

- DTC analysis improved
- Basic Function
  - Data analysis
  - Actuation Test
  - ECU Information Display
- Advanced Function
  - Basic setting
  - Adaptation

### KWP 2000 Type All System

- DTC analysis Function improved

### CAN Type All System

- DTC analysis Function improved
- Long Coding Function improved
- System Recode Module Function enhanced

### UDS Type All System

- ECU INFO Function stabilized
- DTC analysis Function enhanced

### LT3 Instrument Cluster System

- Service reset Function stabilized

### Bosch Type Headlight Range Control System

- Communication stabilized

## JAGUAR

### New Maker added

#### F-TYPE 2014~

##### PCM (Powertrain Control Module)

- Basic Function
- DTC analysis

##### TCM (Transmission Control Module)

- Basic Function
- DTC analysis

##### GSM (Gear Shift Module)

- Basic Function
- DTC analysis

##### ABS (ABS Control Module)

- Basic Function
- DTC analysis

##### RCM (Restraints Control Module)

- Basic Function
- DTC analysis

##### OCS (Restraints Occupancy System)

- Basic Function
- DTC analysis

##### VIM (Vehicle Immobilizer Module)

- Basic Function

##### DTC analysis

##### KVM (Keyless Vehicle Module)

- Basic Function
- DTC analysis

##### BCM (Body Control Module)

- Basic Function
- DTC analysis

##### IPC (Instrument Cluster Control Module)

- Basic Function
- DTC analysis

##### PBM (Parking Brake Control Module)

- Basic Function
- DTC analysis

##### PAM (Parking Assist Control Module)

- Basic Function
- DTC analysis

##### HCM (Headlamp Control Module)

- Basic Function
- DTC analysis

##### HCMB (Headlamp Control Module B)

- Basic Function
- DTC analysis

##### ATCM (All Terrain Control Module)

- Basic Function
- DTC analysis

##### RDCM (Rear Differential Control Module)

- Basic Function
- DTC analysis

##### DDM (Driver's Door Module)

- Basic Function
- DTC analysis

##### PDM (Passenger's Door Module)

- Basic Function
- DTC analysis

##### RGTM (Rear Gate/Trunk Module)

- Basic Function
- DTC analysis

##### DSM (Driver's Seat Module)

- Basic Function
- DTC analysis

##### PSM (Passenger's Seat Module)

- Basic Function
- DTC analysis

##### HVAC (Heating Ventilation and Air Conditioning Control Module)

- Basic Function
- DTC analysis

##### SODL (Side Object Detection - Left)

- Basic Function
- DTC analysis

##### SODR (Side Object Detection - Right)

- Basic Function
- DTC analysis

##### CHCM (Chassis Control Module)

- Basic Function

For more information, please email [sales@e-zds.com](mailto:sales@e-zds.com), or call +82-70-7733-7811 or 7775



DTC analysis	- Basic Function
FTCM (Folding Top Control Module)	DTC analysis
- Basic Function	PBM (Parking Brake Control Module)
DTC analysis	- Basic Function
FTCMB (Folding Top Control Module B)	DTC analysis
- Basic Function	PAM (Parking Assist Control Module)
DTC analysis	- Basic Function
GWM (Gateway Module)	DTC analysis
- Basic Function	HCM (Headlamp Control Module)
DTC analysis	- Basic Function
FCDIM (Front Control/Display Interface Module)	DTC analysis
- Basic Function	ADCM (Adaptive Damping Control Module)
DTC analysis	- Basic Function
FCIM (Front Controls Interface Module)	DTC analysis
- Basic Function	DDM (Driver's Door Module)
DTC analysis	- Basic Function
IPMB (Image Processing Module B)	DTC analysis
- Basic Function	PDM (Passenger's Door Module)
DTC analysis	- Basic Function
	DTC analysis
<b>XF 2008 ~ 2009</b>	DSM (Driver's Seat Module)
PCM (Powertrain Control Module)	- Basic Function
- Basic Function	DTC analysis
DTC analysis	DSCM (Driver's Seat Climate Control Module)
TCM (Transmission Control Module)	- Basic Function
- Basic Function	DTC analysis
DTC analysis	HVAC (Heating Ventilation and Air Conditioning Control Module)
GSM (Gear Shift Module)	- Basic Function
- Basic Function	DTC analysis
DTC analysis	SODL (Side Object Detection - Left)
ABS (ABS Control Module)	- Basic Function
- Basic Function	DTC analysis
DTC analysis	SODR (Side Object Detection - Right)
RCM (Restraints Control Module)	- Basic Function
- Basic Function	DTC analysis
DTC analysis	TPM (Tire Pressure Monitoring System)
OCS (Restraints Occupancy System)	- Basic Function
- Basic Function	DTC analysis
DTC analysis	ICS (Impact Classification System)
VIM (Vehicle Immobilizer Module)	- Basic Function
- Basic Function	DTC analysis
DTC analysis	CCM (Adaptive Speed Control Module)
KVM (Keyless Vehicle Module)	- Basic Function
- Basic Function	DTC analysis
DTC analysis	ICM (Infotainment Control Module)
BCM (Body Control Module)	- Basic Function
- Basic Function	DTC analysis
DTC analysis	
BCMB (Body Control Module B)	
- Basic Function	<b>XF 2010 ~ 2011</b>
DTC analysis	PCM (Powertrain Control Module)
IPC (Instrument Cluster Control Module)	- Basic Function
- Basic Function	DTC analysis
DTC analysis	- Advanced Function
ICP (Integrated Control Panel)	Oil service counter reset (Petrol Only)

- TCM (Transmission Control Module)
  - Basic Function
  - DTC analysis
- GSM (Gear Shift Module)
  - Basic Function
  - DTC analysis
- ABS (ABS Control Module)
  - Basic Function
  - DTC analysis
- RCM (Restraints Control Module)
  - Basic Function
  - DTC analysis
- OCS (Restraints Occupancy System)
  - Basic Function
  - DTC analysis
- VIM (Vehicle Immobilizer Module)
  - Basic Function
  - DTC analysis
- KVM (Keyless Vehicle Module)
  - Basic Function
  - DTC analysis
- BCM (Body Control Module)
  - Basic Function
  - DTC analysis
- BCMB (Body Control Module B)
  - Basic Function
  - DTC analysis
- IPC (Instrument Cluster Control Module)
  - Basic Function
  - DTC analysis
- ICP (Integrated Control Panel)
  - Basic Function
  - DTC analysis
- PBM (Parking Brake Control Module)
  - Basic Function
  - DTC analysis
- PAM (Parking Assist Control Module)
  - Basic Function
  - DTC analysis
- HCM (Headlamp Control Module)
  - Basic Function
  - DTC analysis
- ADCM (Adaptive Damping Control Module)
  - Basic Function
  - DTC analysis
- RDCM (Rear Differential Control Module)
  - Basic Function
  - DTC analysis
- DDM (Driver's Door Module)
  - Basic Function
  - DTC analysis
- PDM (Passenger's Door Module)
  - Basic Function
  - DTC analysis
- DSM (Driver's Seat Module)
  - Basic Function
  - DTC analysis
- Basic Function
  - DTC analysis
- DCSM (Driver's Seat Climate Control Module)
  - Basic Function
  - DTC analysis
- HVAC (Heating Ventilation and Air Conditioning Control Module)
  - Basic Function
  - DTC analysis
- SODL (Side Object Detection - Left)
  - Basic Function
  - DTC analysis
- SODR (Side Object Detection - Right)
  - Basic Function
  - DTC analysis
- TPM (Tire Pressure Monitoring System)
  - Basic Function
  - DTC analysis
- ICS (Impact Classification System)
  - Basic Function
  - DTC analysis
- CCM (Adaptive Speed Control Module)
  - Basic Function
  - DTC analysis
- ICM (Infotainment Control Module)
  - Basic Function
  - DTC analysis
- XF 2012**
- PCM (Powertrain Control Module)
  - Basic Function
  - DTC analysis
  - Advanced Function
    - Oil service counter reset (Petrol Only)
- TCM (Transmission Control Module)
  - Basic Function
  - DTC analysis
- GSM (Gear Shift Module)
  - Basic Function
  - DTC analysis
- ABS (ABS Control Module)
  - Basic Function
  - DTC analysis
- RCM (Restraints Control Module)
  - Basic Function
  - DTC analysis
- OCS (Restraints Occupancy System)
  - Basic Function
  - DTC analysis
- VIM (Vehicle Immobilizer Module)
  - Basic Function
  - DTC analysis
- KVM (Keyless Vehicle Module)
  - Basic Function
  - DTC analysis

For more information, please email [sales@e-zds.com](mailto:sales@e-zds.com), or call +82-70-7733-7811 or 7775

- BCM (Body Control Module)  
- Basic Function  
DTC analysis
- BCMB (Body Control Module B)  
- Basic Function  
DTC analysis
- IPC (Instrument Cluster Control Module)  
- Basic Function  
DTC analysis
- PBM (Parking Brake Control Module)  
- Basic Function  
DTC analysis
- PAM (Parking Assist Control Module)  
- Basic Function  
DTC analysis
- HCM (Headlamp Control Module)  
- Basic Function  
DTC analysis
- HCMB (Headlamp Control Module B)  
- Basic Function  
DTC analysis
- ADCM (Adaptive Damping Control Module)  
- Basic Function  
DTC analysis
- RDCM (Rear Differential Control Module)  
- Basic Function  
DTC analysis
- DDM (Driver's Door Module)  
- Basic Function  
DTC analysis
- PDM (Passenger's Door Module)  
- Basic Function  
DTC analysis
- SPMA (Seatbelt Pre-tensioner Control Module A)  
- Basic Function  
DTC analysis
- SPMB (Seatbelt Pre-tensioner Control Module B)  
- Basic Function  
DTC analysis
- DSM (Driver's Seat Module)  
- Basic Function  
DTC analysis
- PSM (Passenger's Seat Module)  
- Basic Function  
DTC analysis
- DSCM (Driver's Seat Climate Control Module)  
- Basic Function  
DTC analysis
- HVAC (Heating Ventilation and Air Conditioning Control Module)  
- Basic Function  
DTC analysis
- SODL (Side Object Detection - Left)  
- Basic Function  
DTC analysis
- SODR (Side Object Detection - Right)  
- Basic Function  
DTC analysis
- TPM (Tire Pressure Monitoring System)  
- Basic Function  
DTC analysis
- ICS (Impact Classification System)  
- Basic Function  
DTC analysis
- GWM (Gateway Module)  
- Basic Function  
DTC analysis
- CCM (Adaptive Speed Control Module)  
- Basic Function  
DTC analysis
- FCDIM (Front Control/Display Interface Module)  
- Basic Function  
DTC analysis
- FCIMB (Front Controls Interface Module B)  
- Basic Function  
DTC analysis
- XF 2013 ~**
- PCM (Powertrain Control Module)  
- Basic Function  
DTC analysis
- TCM (Transmission Control Module)  
- Basic Function  
DTC analysis
- TCCM (Transfer Case Control Module)  
- Basic Function  
DTC analysis
- GSM (Gear Shift Module)  
- Basic Function  
DTC analysis
- ABS (ABS Control Module)  
- Basic Function  
DTC analysis
- RCM (Restraints Control Module)  
- Basic Function  
DTC analysis
- OCS (Restraints Occupancy System)  
- Basic Function  
DTC analysis
- VIM (Vehicle Immobilizer Module)  
- Basic Function  
DTC analysis
- KVM (Keyless Vehicle Module)  
- Basic Function  
DTC analysis
- BCM (Body Control Module)  
- Basic Function  
DTC analysis
- BCMB (Body Control Module B)  
- Basic Function

DTC analysis  
IPC (Instrument Cluster Control Module)  
- Basic Function  
DTC analysis  
PBM (Parking Brake Control Module)  
- Basic Function  
DTC analysis  
PAM (Parking Assist Control Module)  
- Basic Function  
DTC analysis  
HCM (Headlamp Control Module)  
- Basic Function  
DTC analysis  
HCMB (Headlamp Control Module B)  
- Basic Function  
DTC analysis  
ADCM (Adaptive Damping Control Module)  
- Basic Function  
DTC analysis  
RDCM (Rear Differential Control Module)  
- Basic Function  
DTC analysis  
DDM (Driver's Door Module)  
- Basic Function  
DTC analysis  
PDM (Passenger's Door Module)  
- Basic Function  
DTC analysis  
RGTM (Rear Gate/Trunk Module)  
- Basic Function  
DTC analysis  
SPMA (Seatbelt Pre-tensioner Control Module A)  
- Basic Function  
DTC analysis  
SPMB (Seatbelt Pre-tensioner Control Module B)  
- Basic Function  
DTC analysis  
DSM (Driver's Seat Module)  
- Basic Function  
DTC analysis  
PSM (Passenger's Seat Module)  
- Basic Function  
DTC analysis  
DCSM (Driver's Seat Climate Control Module)  
- Basic Function  
DTC analysis  
HVAC (Heating Ventilation and Air Conditioning Control Module)  
- Basic Function  
DTC analysis  
SODL (Side Object Detection - Left)  
- Basic Function  
DTC analysis  
SODR (Side Object Detection - Right)  
- Basic Function

DTC analysis  
CHCM (Chassis Control Module)  
- Basic Function  
DTC analysis  
TPM (Tire Pressure Monitoring System)  
- Basic Function  
DTC analysis  
GWM (Gateway Module)  
- Basic Function  
DTC analysis  
CCM (Adaptive Speed Control Module)  
- Basic Function  
DTC analysis  
FCDIM (Front Control/Display Interface Module)  
- Basic Function  
DTC analysis  
FCIMB (Front Controls Interface Module B)  
- Basic Function  
DTC analysis

**XJ SERIES 2006 ~ 2007**

PCM (Powertrain Control Module)  
- Basic Function  
DTC analysis  
ABS (ABS Control Module)  
- Basic Function  
DTC analysis  
PBM (Parking Brake Control Module)  
- Basic Function  
DTC analysis  
TPM (Tire Pressure Monitoring System)  
- Basic Function  
DTC analysis

**XJ SERIES 2008 ~ 2009**

PCM (Powertrain Control Module)  
- Basic Function  
DTC analysis  
ABS (ABS Control Module)  
- Basic Function  
DTC analysis  
PBM (Parking Brake Control Module)  
- Basic Function  
DTC analysis  
DCSM (Driver's Seat Climate Control Module)  
- Basic Function  
DTC analysis  
TPM (Tire Pressure Monitoring System)  
- Basic Function  
DTC analysis

**XJ SERIES 2010 ~ 2012**

PCM (Powertrain Control Module)  
- Basic Function  
DTC analysis

- |  |  |
|--|--|
| TCM (Transmission Control Module)              | - Basic Function   |
| - Basic Function                               | DTC analysis   |
| GSM (Gear Shift Module)                        | SPMB (Seatbelt Pre-tensioner Control Module B)                       |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| ABS (ABS Control Module)                       | DSM (Driver's Seat Module)   |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| RCM (Restraints Control Module)                | PSM (Passenger's Seat Module)  |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| OCS (Restraints Occupancy System)              | RLSM (Rear Left Seat Module)   |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| VIM (Vehicle Immobilizer Module)               | RRSM (Rear Right Seat Module)  |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| KVM (Keyless Vehicle Module)                   | DCSM (Driver's Seat Climate Control Module)                          |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| BCM (Body Control Module)                      | RDCSM (Rear Seat Climate Control Module)                             |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| IPC (Instrument Cluster Control Module)        | HVAC (Heating Ventilation and Air Conditioning Control Module)       |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| PBM (Parking Brake Control Module)             | RHVAC (Rear Heating Ventilation and Air Conditioning Control Module) |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| PAM (Parking Assist Control Module)            | SODL (Side Object Detection - Left)                                  |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| HCM (Headlamp Control Module)                  | SODR (Side Object Detection - Right)                                 |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| HCMB (Headlamp Control Module B)               | RLM (Ride Level Control Module)                                      |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| ADCM (Adaptive Damping Control Module)         | CCM (Adaptive Speed Control Module)                                  |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| RDCM (Rear Differential Control Module)        | FCDIM (Front Control/Display Interface Module)                       |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| DDM (Driver's Door Module)                     | FCIMB (Front Controls Interface Module B)                            |
| - Basic Function                               | - Basic Function   |
| DTC analysis                                   | DTC analysis   |
| PDM (Passenger's Door Module)                  |  |
| - Basic Function                               |  |
| DTC analysis                                   |  |
| RGTM (Rear Gate/Trunk Module)                  | <b>XJ SERIES 2013 ~</b>  |
| - Basic Function                               | PCM (Powertrain Control Module)                                      |
| DTC analysis                                   | - Basic Function   |
| SPMA (Seatbelt Pre-tensioner Control Module A) | DTC analysis   |
|  | TCM (Transmission Control Module)                                    |

For more information, please email [sales@e-zds.com](mailto:sales@e-zds.com), or call +82-70-7733-7811 or 7775

- Basic Function
  - DTC analysis
  - TCCM (Transfer Case Control Module)
  - Basic Function
  - DTC analysis
  - GSM (Gear Shift Module)
  - Basic Function
  - DTC analysis
  - ABS (ABS Control Module)
  - Basic Function
  - DTC analysis
  - RCM (Restraints Control Module)
  - Basic Function
  - DTC analysis
  - OCS (Restraints Occupancy System)
  - Basic Function
  - DTC analysis
  - VIM (Vehicle Immobilizer Module)
  - Basic Function
  - DTC analysis
  - KVM (Keyless Vehicle Module)
  - Basic Function
  - DTC analysis
  - BCM (Body Control Module)
  - Basic Function
  - DTC analysis
  - IPC (Instrument Cluster Control Module)
  - Basic Function
  - DTC analysis
  - PBM (Parking Brake Control Module)
  - Basic Function
  - DTC analysis
  - PAM (Parking Assist Control Module)
  - Basic Function
  - DTC analysis
  - HCM (Headlamp Control Module)
  - Basic Function
  - DTC analysis
  - HCMB (Headlamp Control Module B)
  - Basic Function
  - DTC analysis
  - RDCM (Rear Differential Control Module)
  - Basic Function
  - DTC analysis
  - DDM (Driver's Door Module)
  - Basic Function
  - DTC analysis
  - PDM (Passenger's Door Module)
  - Basic Function
  - DTC analysis
  - RGTM (Rear Gate/Trunk Module)
  - Basic Function
  - DTC analysis
  - DSM (Driver's Seat Module)
  - Basic Function
  - DTC analysis
  - PSM (Passenger's Seat Module)
  - Basic Function
  - DTC analysis
  - RLSM (Rear Left Seat Module)
  - Basic Function
  - DTC analysis
  - RRSM (Rear Right Seat Module)
  - Basic Function
  - DTC analysis
  - DCSM (Driver's Seat Climate Control Module)
  - Basic Function
  - DTC analysis
  - RDCSM (Rear Seat Climate Control Module)
  - Basic Function
  - DTC analysis
  - HVAC (Heating Ventilation and Air Conditioning Control Module)
  - Basic Function
  - DTC analysis
  - RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)
  - Basic Function
  - DTC analysis
  - SODL (Side Object Detection - Left)
  - Basic Function
  - DTC analysis
  - SODR (Side Object Detection - Right)
  - Basic Function
  - DTC analysis
  - CHCM (Chassis Control Module)
  - Basic Function
  - DTC analysis
  - GWM (Gateway Module)
  - Basic Function
  - DTC analysis
  - CCM (Adaptive Speed Control Module)
  - Basic Function
  - DTC analysis
  - FCDIM (Front Control/Display Interface Module)
  - Basic Function
  - DTC analysis
  - FCIMB (Front Controls Interface Module B)
  - Basic Function
  - DTC analysis
- XK 2006 ~ 2009**
- PCM (Powertrain Control Module)
  - Basic Function
  - DTC analysis
  - TCM (Transmission Control Module)
  - Basic Function
  - DTC analysis
  - ABS (ABS Control Module)
  - Basic Function

For more information, please email [sales@e-zds.com](mailto:sales@e-zds.com), or call +82-70-7733-7811 or 7775

DTC analysis  
RCM (Restraints Control Module)  
- Basic Function  
DTC analysis  
VIM (Vehicle Immobilizer Module)  
- Basic Function  
DTC analysis  
KVM (Keyless Vehicle Module)  
- Basic Function  
DTC analysis  
BCM (Body Control Module)  
- Basic Function  
DTC analysis  
BCMB (Body Control Module B)  
- Basic Function  
DTC analysis  
IPC (Instrument Cluster Control Module)  
- Basic Function  
DTC analysis  
ICP (Integrated Control Panel)  
- Basic Function  
DTC analysis  
PBM (Parking Brake Control Module)  
- Basic Function  
DTC analysis  
PAM (Parking Assist Control Module)  
- Basic Function  
DTC analysis  
HCM (Headlamp Control Module)  
- Basic Function  
DTC analysis  
ADCM (Adaptive Damping Control Module)  
- Basic Function  
DTC analysis  
DDM (Driver's Door Module)  
- Basic Function  
DTC analysis  
PDM (Passenger's Door Module)  
- Basic Function  
DTC analysis  
DSM (Driver's Seat Module)  
- Basic Function  
DTC analysis  
PSM (Passenger's Seat Module)  
- Basic Function  
DTC analysis  
HVAC (Heating Ventilation and Air Conditioning Control Module)  
- Basic Function  
DTC analysis  
TPM (Tire Pressure Monitoring System)  
- Basic Function  
DTC analysis  
ICS (Impact Classification System)  
- Basic Function

DTC analysis  
FTCM (Folding Top Control Module)  
- Basic Function  
DTC analysis  
CCM (Adaptive Speed Control Module)  
- Basic Function  
DTC analysis  
ICM (Infotainment Control Module)  
- Basic Function  
DTC analysis  
**XK 2010 ~**  
PCM (Powertrain Control Module)  
- Basic Function  
DTC analysis  
- Advanced Function  
Oil service counter reset (Petrol Only)  
TCM (Transmission Control Module)  
- Basic Function  
DTC analysis  
GSM (Gear Shift Module)  
- Basic Function  
DTC analysis  
ABS (ABS Control Module)  
- Basic Function  
DTC analysis  
RCM (Restraints Control Module)  
- Basic Function  
DTC analysis  
OCS (Restraints Occupancy System)  
- Basic Function  
DTC analysis  
VIM (Vehicle Immobilizer Module)  
- Basic Function  
DTC analysis  
KVM (Keyless Vehicle Module)  
- Basic Function  
DTC analysis  
BCM (Body Control Module)  
- Basic Function  
DTC analysis  
BCMB (Body Control Module B)  
- Basic Function  
DTC analysis  
IPC (Instrument Cluster Control Module)  
- Basic Function  
DTC analysis  
ICP (Integrated Control Panel)  
- Basic Function  
DTC analysis  
PBM (Parking Brake Control Module)  
- Basic Function  
DTC analysis  
PAM (Parking Assist Control Module)  
- Basic Function

DTC analysis  
 HCM (Headlamp Control Module)  
 - Basic Function  
 DTC analysis  
 ADCM (Adaptive Damping Control Module)  
 - Basic Function  
 DTC analysis  
 RDCM (Rear Differential Control Module)  
 - Basic Function  
 DTC analysis  
 DDM (Driver's Door Module)  
 - Basic Function  
 DTC analysis  
 PDM (Passenger's Door Module)  
 - Basic Function  
 DTC analysis  
 DSM (Driver's Seat Module)  
 - Basic Function  
 DTC analysis  
 PSM (Passenger's Seat Module)  
 - Basic Function  
 DTC analysis  
 DCSCM (Driver's Seat Climate Control Module)  
 - Basic Function  
 DTC analysis  
 HVAC (Heating Ventilation and Air Conditioning Control Module)  
 - Basic Function  
 DTC analysis  
 TPM (Tire Pressure Monitoring System)  
 - Basic Function  
 DTC analysis  
 ICS (Impact Classification System)  
 - Basic Function  
 DTC analysis  
 FTCM (Folding Top Control Module)  
 - Basic Function  
 DTC analysis  
 CCM (Adaptive Speed Control Module)  
 - Basic Function  
 DTC analysis  
 ICM (Infotainment Control Module)  
 - Basic Function  
 DTC analysis

Actuation Test  
 ECU Information  
 - Advanced Function  
 Resetting counter particle filter  
 Adaptation of throttle module  
 Adaptation of the exhaust gas recirculation (EGR) valve  
 Adaptation of differential pressure sensor particle filter  
 Adjusting calculated oil level

ECM (D5204T5)  
 - Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information

ECM (D5244T15)  
 - Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information  
 - Advanced Function  
 Resetting counter particle filter  
 Adaptation of throttle module  
 Adaptation of the exhaust gas recirculation (EGR) valve  
 Adaptation of differential pressure sensor particle filter  
 Adjusting calculated oil level

ECM (B4164T)  
 - Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information

ECM (B5254T5)  
 - Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information

TCM (TF-80SC)  
 - Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information  
 - Advanced Function  
 Resetting adaptation

### VOLVO

#### C30 2009~2012 New Model added

ECM (D5204T6)  
 - Basic Function  
 DTC Analysis  
 Data Analysis

For more information, please email [sales@e-zds.com](mailto:sales@e-zds.com), or call +82-70-7733-7811 or 7775



Resetting the 'Transmission fluid change' counter  
Activating gear indication  
Control module adaptation

- Advanced Function  
Resetting the service reminder indicator (SRI)  
Resetting the information to zero on power supply  
when replacing the battery

**TCM (TG-81SC)**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information

**PDM (Passenger door module)**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information

**ABS (Anti-Lock Brake System)**

- Basic Function  
DTC Analysis  
ECU Information

**DDM (Driver door module)**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information

**SAS (Steering Angle Sensor module)**

- Basic Function  
DTC Analysis  
Data Analysis  
ECU Information

**PSM (Power Seat Module)**

- Basic Function  
DTC Analysis  
ECU Information

**BCM (Brake Control Module)**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information

**CCM (Climate Control Module)**

- Basic Function  
DTC Analysis  
ECU Information

**SRS (Supplemental Restraint System)**

- Basic Function  
DTC Analysis  
Data Analysis  
ECU Information

**EPS (Electrical power steering module)**

- Basic Function  
DTC Analysis  
Data Analysis  
ECU Information

**DIM (Driver Information Module)**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information  
- Advanced Function  
Testing all indicators and lamps in the driver  
information module (DIM)  
Resetting the service reminder indicator (SRI)  
Display of DSTC message  
Programming the driver information module (DIM)  
Programming the gear shift indicator

**SWM (Steering Wheel Module)**

- Basic Function  
DTC Analysis  
ECU Information

**HCM (Headlamp control module)**

- Basic Function  
DTC Analysis  
Data Analysis  
ECU Information

**CEM (Central Electronic Module)**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information

**XC60 2015 New Model added**

**ECM (D4204T5)**  
- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information  
- Advanced Function  
Test of fuel flow regulation valve

Testing the fuel pressure control valve  
 Resetting adaptations for fuel flow regulation valve  
 Resetting adaptations for swirl damper  
 Resetting adaptations for turbocharger control  
 Resetting adaptations for the EGR valve  
 Resetting adaptations for the diesel particle filter  
 Resetting adaptations for the particle filter's  
 differential pressure sensor  
 Resetting adaptations for rear heated oxygen  
 sensor  
 Resetting adaptations for the injectors  
 Resetting adaptations for the neutral position  
 sensor

**ECM (D5204T6)**

- Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information  
 - Advanced Function  
 Resetting counter particle filter  
 Adaptation of throttle module  
 Adaptation of the exhaust gas recirculation (EGR)  
 valve  
 Adaptation of differential pressure sensor particle  
 filter  
 Adjusting calculated oil level

**ECM (D5204T5)**

- Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information

**ECM (D5244T15)**

- Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information  
 - Advanced Function  
 Resetting counter particle filter  
 Adaptation of throttle module  
 Adaptation of the exhaust gas recirculation (EGR)  
 valve  
 Adaptation of differential pressure sensor particle  
 filter  
 Adjusting calculated oil level

**ECM (B4164T)**

- Basic Function  
 DTC Analysis  
 Data Analysis

Actuation Test  
 ECU Information

**ECM (B5254T5)**

- Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information

**ECM (B6324S)**

- Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information  
 - Advanced Function  
 Resetting the adaptation values

**TCM (TF-80SC)**

- Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information  
 - Advanced Function  
 Resetting adaptation  
 Resetting the 'Transmission fluid change' counter  
 Activating gear indication  
 Control module adaptation

**TCM (TG-81SC)**

- Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information

**SAS (Steering Angle Sensor module)**

- Basic Function  
 DTC Analysis  
 Data Analysis  
 ECU Information

**BCM (Brake Control Module)**

- Basic Function  
 DTC Analysis  
 Data Analysis  
 Actuation Test  
 ECU Information

**PBM(Park Brake Module)**

- Basic Function  
 DTC Analysis  
 Data Analysis  
 ECU Information

- Advanced Function Activation and service	Data Analysis ECU Information
SRS (Supplemental Restraint System)	PDM (Passenger door module)
- Basic Function DTC Analysis Data Analysis ECU Information	- Basic Function DTC Analysis Data Analysis Actuation Test ECU Information
PSCM (Power Steering Control Module)	- Advanced Function Initializing the window in the front door Initializing the window in the rear door
- Basic Function DTC Analysis Data Analysis ECU Information	CCM (Climate control module)
FSM (Forward Sensing Module)	- Basic Function DTC Analysis Data Analysis Actuation Test ECU Information
- Basic Function DTC Analysis Data Analysis ECU Information	AUD (Audio Module)
CVM (Closing Velocity Module)	- Basic Function DTC Analysis ECU Information
- Basic Function DTC Analysis Data Analysis ECU Information	DDM (Driver Door Module)
DIM (Driver Information Module)	- Basic Function DTC Analysis Data Analysis Actuation Test ECU Information
- Basic Function DTC Analysis Data Analysis ECU Information	- Advanced Function Initializing the window in the front door Initializing the window in the rear door
- Advanced Function Resetting the service reminder indicator (SRI)	PSM (Power Seat Module)
PAM (Parking Assistance Module)	- Basic Function DTC Analysis Data Analysis Actuation Test ECU Information
- Basic Function DTC Analysis Data Analysis ECU Information	DEM (Differential Electronic Module)
CEM (Central Electrical Module)	- Basic Function DTC Analysis Data Analysis ECU Information
- Basic Function DTC Analysis Data Analysis Actuation Test ECU Information	POT (Power operated tailgate module)
- Advanced Function Resetting the information to zero on power supply when replacing the battery Programming of rear window wiper when reversing	- Basic Function DTC Analysis Data Analysis ECU Information
ICM (Infotainment Control Module)	SODR (Side Obstacle Detection control module Right)
- Basic Function DTC Analysis	

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information

**SODL (Side Obstacle Detection control module Left)**

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information

**RDAR (Remote Digital Audio Receiver)**

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information

**BPM (Bluetooth phone module)**

- Basic Function
- DTC Analysis
- ECU Information

## PEUGEOT

**208 New Mode added**
**Driving assistance Comfort**

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information

**Built-In system interface**

- Basic Function
- DTC Analysis
- ECU Information
- Advanced Function
- Reset to zero of the counter for the number of restarts

**Multiplexed control panel**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

**External CD player**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

**Air conditioning**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

**Instrument panel**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

**Switch module at the steering wheel**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

**Engine (ME749\_EC5)**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

**Engine (5FW MEV 17.4)**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Advanced Function
- Initialization of autoadaptatives

**Engine (8FS MEV 17.4)**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Advanced Function
- Initialization of autoadaptatives

**Engine (5FS MEV 17.4 EVO)**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Advanced Function
- Initialization of autoadaptatives

For more information, please email [sales@e-zds.com](mailto:sales@e-zds.com), or call +82-70-7733-7811 or 7775

Engine (V46\_21)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Engine (9HX EDC16C3)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Engine (9HY EDC16C3)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Engine (9HZ EDC16C3)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Engine (9HV EDC16C3)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Engine (RHR DCM 3.4)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Engine (RHL DCM 3.4)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Engine (RHF DCM 3.4)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test

ECU Information

Gearbox ECU (AM6 Euro5 automatic gearbox)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Gearbox ECU (AT6 Euro5 automatic gearbox)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Gearbox ECU (CFC300P gearbox)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Gearbox ECU (BVA\_AL4)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

ABS or ESP

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Airbag

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information
- Advanced Function
- Locking
- Unlocking

**Partner B9 Vehicle Added**

- Power steering
- Basic Function
- DTC Analysis
- Actuation Test
- ECU Information

Parking aid

- Basic Function

DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information  
- Advanced Function  
Configuration

**Built-In system interface**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information

**Multifunction display**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information

**Bodywork conversion unit**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information

**Instrument panel**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information  
- Advanced Function  
Configuration  
Service zero reset

**Switch module at the steering wheel**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information

**Engine (ME745 NFU)**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information  
- Advanced Function  
Initializing the autoadaptives

**Engine (ME745 N6B)**

- Basic Function

DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information  
- Advanced Function  
Initializing the autoadaptives

**Engine (ME745 N6A)**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information  
- Advanced Function  
Initializing the autoadaptives

**Engine (ME745 NFR)**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information  
- Advanced Function  
Initializing the autoadaptives

**Engine (5FW MEV 17.4)**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information  
- Advanced Function  
Initialization of autoadaptatives

**Engine (8FS MEV 17.4)**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information  
- Advanced Function  
Initialization of autoadaptatives

**Engine (5FS MEV 17.4 EVO)**

- Basic Function  
DTC Analysis  
Data Analysis  
Actuation Test  
ECU Information  
- Advanced Function  
Initialization of autoadaptatives

**Engine (5FV MED17.4.2 EURO 5)**

- Basic Function  
DTC Analysis

Data Analysis Actuation Test ECU Information	DTC Analysis Data Analysis Actuation Test ECU Information
Engine (V46_21) - Basic Function DTC Analysis Data Analysis Actuation Test ECU Information	- Advanced Function Forced Regeneration Of The Particle Filter Vehicle Stationary Initialization of the additive level when filling or replacing the additive reservoir Replacement Of The Diesel Additive Reservoir Of The Pump Or Of The Pipes Replacement Of The Particle Emission Filter
Engine (9HX EDC16C3) - Basic Function DTC Analysis Data Analysis Actuation Test ECU Information	Gearbox ECU (Auto gearbox AL4) - Basic Function DTC Analysis Data Analysis Actuation Test ECU Information
Engine (9HY EDC16C3) - Basic Function DTC Analysis Data Analysis Actuation Test ECU Information	Gearbox ECU (AM6 Euro5) - Basic Function DTC Analysis Data Analysis Actuation Test ECU Information
Engine (9HZ EDC16C3) - Basic Function DTC Analysis Data Analysis Actuation Test ECU Information	Gearbox ECU (AT6 Euro5) - Basic Function DTC Analysis Data Analysis Actuation Test ECU Information
Engine (9HV EDC16C3) - Basic Function DTC Analysis Data Analysis Actuation Test ECU Information	Gearbox ECU (CFC300P) - Basic Function DTC Analysis Data Analysis Actuation Test ECU Information
Engine (RHR DCM 3.4) - Basic Function DTC Analysis Data Analysis Actuation Test ECU Information	Gearbox ECU (BVA_AT8) - Basic Function DTC Analysis Data Analysis Actuation Test ECU Information
Engine (9HR HDI SID807) - Basic Function DTC Analysis Data Analysis Actuation Test ECU Information	Engine relay unit - Basic Function DTC Analysis
Engine (RHR SIEMENS SID803A) - Basic Function	Trailer relay unit - Basic Function DTC Analysis

Windscreen wiper

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

ABS or ESP

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Electric secondary brake

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Advanced Function
- Brake cable replacement
- Electric parking brake replacement

Airbag

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information
- Advanced Function
- Configuration
- Locking
- Unlocking

## CITROEN

**Berlingo Systems Added**

Engine (9HN-DV6ETED)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Engine (9HX DV6AUTED4 - 90 CV)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Advanced Function

Forced Regeneration Of The Particle Filter Vehicle Stationary

- Initialization of the additive level when filling or replacing the additive reservoir
- Replacement Of The Diesel Additive Reservoir Of The Pump Or Of The Pipes
- Replacement Of The Particle Emission Filter

Engine (9HX-DV6ATED4 - 90 CV)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Advanced Function

Forced Regeneration Of The Particle Filter Vehicle Stationary

- Initialization of the additive level when filling or replacing the additive reservoir
- Replacement Of The Diesel Additive Reservoir Of The Pump Or Of The Pipes
- Replacement Of The Particle Emission Filter

Engine (9HZ-DV6TED4 FAP - 110 CV)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Advanced Function

Forced Regeneration Of The Particle Filter Vehicle Stationary

- Initialization of the additive level when filling or replacing the additive reservoir
- Replacement Of The Diesel Additive Reservoir Of The Pump Or Of The Pipes
- Replacement Of The Particle Emission Filter

Power steering electric pump unit

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information

Radio (RD4)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Radio (RD5)

- Basic Function
- DTC Analysis
- Data Analysis



Actuation Test  
ECU Information

Rain sensor / Brightness

- Basic Function
- DTC Analysis
- ECU Information

Trailer relay unit

- Basic Function
- DTC Analysis

Engine relay unit

- Basic Function
- DTC Analysis

Multiplexed additive pump

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Advanced Function
- Replacement of the additive tank
- Replacement of the additive pump

Multifunction display

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

## FIAT

**TRW Airbag MY12 New Type added**

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information

**Instrument Panel Marelli MY12 New Type added**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Advanced Function
- Activate seat belt alarm
- Next service reset

**Delphi Electric Steering MY12 New Type added**

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information
- Advanced Function
- Position sensor calibration
- Torque/position calibrations reset

**Body Computer Marelli(940) New Type added**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Advanced Function
- Power supply mode
- Rearm inertia switch (FIS)
- Indicators command

**Instrument Panel Marelli Advanced Function added**

- Advanced Function
- Next service reset

**Instrument Panel Marelli Advanced Function added**

- Advanced Function
- Next service reset

**Instrument Panel Marelli II Advanced Function added**

- Advanced Function
- Next service reset

**Instrument Panel Mannesman VDO Advanced Function added**

- Advanced Function
- Next service reset

**Bug fixed**

**Bosch EDC15C7 CF3/EOBD Diesel Injection (1.9, 2.4)**

- Stabilized

**Bosch Motronic Me7.3.1 EOBD Injection**

- Stabilized

**Continental MK60EC ABS**

- Stabilized

**Delphi Electric Steering (2)**

- Stabilized

**Body Computer Marelli**

- Stabilized

**Instrument Panel Mannesman VDO**

- Stabilized

**Instrument Panel Marelli II**

- Stabilized

**Instrument Panel Marelli**

- Stabilized

**Parking Control VALEO**

- Stabilized
- Driver's Door TRW**
- Stabilized

## ALFA ROMEO

**TRW Airbag MY12 New Type added**

- Basic Function
  - DTC Analysis
  - Data Analysis
  - ECU Information

**Instrument Panel Marelli MY12 New Type added**

- Basic Function
  - DTC Analysis
  - Data Analysis
  - Actuation Test
  - ECU Information
- Advanced Function
  - Activate seat belt alarm
  - Next service reset

**Delphi Electric Steering MY12 New Type added**

- Basic Function
  - DTC Analysis
  - Data Analysis
  - ECU Information
- Advanced Function
  - Position sensor calibration
  - Torque/position calibrations reset

**Body Computer Marelli(940) New Type added**

- Basic Function
  - DTC Analysis
  - Data Analysis
  - Actuation Test
  - ECU Information
- Advanced Function
  - Power supply mode
  - Rearm inertia switch (FIS)
  - Indicators command

**Instrument Panel Marelli Advanced Function added**

- Advanced Function
  - Next service reset

**Instrument Panel Marelli Advanced Function added**

- Advanced Function
  - Next service reset

**Instrument Panel Marelli II Advanced Function added**

- Advanced Function
  - Next service reset

**Instrument Panel Mannesman VDO Advanced Function added**

- Advanced Function
  - Next service reset

**Bug fixed****Bosch EDC15C7 CF3/EOBD Diesel Injection (1.9, 2.4)**

- Stabilized

**Bosch Motronic Me7.3.1 EOBD Injection**

- Stabilized

**Continental MK60EC ABS**

- Stabilized

**Delphi Electric Steering (2)**

- Stabilized

**Body Computer Marelli**

- Stabilized

**Instrument Panel Mannesman VDO**

- Stabilized

**Instrument Panel Marelli II**

- Stabilized

**Instrument Panel Marelli**

- Stabilized

**Parking Control VALEO**

- Stabilized

**Driver's Door TRW**

- Stabilized

## LANCIA

**TRW Airbag MY12 New Type added**

- Basic Function
  - DTC Analysis
  - Data Analysis
  - ECU Information

**Instrument Panel Marelli MY12 New Type added**

- Basic Function
  - DTC Analysis
  - Data Analysis
  - Actuation Test
  - ECU Information
- Advanced Function
  - Activate seat belt alarm
  - Next service reset

**Delphi Electric Steering MY12 New Type added**

- Basic Function
  - DTC Analysis
  - Data Analysis

- ECU Information
- Advanced Function
- Position sensor calibration
- Torque/position calibrations reset

**Body Computer Marelli(940) New Type added**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Advanced Function
- Power supply mode
- Rearm inertia switch (FIS)
- Indicators command

**Instrument Panel Marelli Advanced Function added**

- Advanced Function
- Next service reset

**Instrument Panel Marelli Advanced Function added**

- Advanced Function
- Next service reset

**Instrument Panel Marelli II Advanced Function added**

- Advanced Function
- Next service reset

**Instrument Panel Mannesman VDO Advanced Function added**

- Advanced Function
- Next service reset

**Bug fixed**
**Bosch EDC15C7 CF3/EOBD Diesel Injection (1.9, 2.4)**

- Stabilized

**Bosch Motronic Me7.3.1 EOBD Injection**

- Stabilized

**Continental MK60EC ABS**

- Stabilized

**Delphi Electric Steering (2)**

- Stabilized

**Body Computer Marelli**

- Stabilized

**Instrument Panel Mannesman VDO**

- Stabilized

**Instrument Panel Marelli II**

- Stabilized

**Instrument Panel Marelli**

- Stabilized

**Parking Control VALEO**

- Stabilized

**Driver's Door TRW**

- Stabilized

## LANDROVER

**Bug Fixed**
**Freelander 2007~2010**
**IPC**

- Advanced Function
- Service Interval Reset fixed

**Freelander 2011~2012**
**IPC**

- Advanced Function
- Service Interval Reset fixed

## RENAULT

**Trafic II – System added**
**ABS**

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Info
- Advanced Function
- Bleed Front L/H Wheel
- Bleed Front R/H Wheel
- Bleed Rear L/H Wheel
- Bleed Rear R/H Wheel
- Speedo index
- Write date of last after sales operation

**Logan – Function added**
**UCH**

- Advanced Function
- Originally fitted perimetric protection
- De-ice function
- Starter relay request
- Illuminate hazard lamps upon impact
- Automatic relocking
- Raid function authorisation by diag
- vehicle locked by autolock when driving function
- Timer courtesy light
- Heated rear screen when driving
- Airbag
- Courtesy light timer
- Key type
- Second fitting alarm
- Radio frequency function
- Overspeed alarm for arabia
- Engine type

Configuration privee 31  
Interval variation with speed  
Locking with key  
Seat belt unfastened detection  
Verrou logique (software lock)  
Central locking button type

**Megane II – Function added**

## Instrument Panel

- Advanced Function
  - Update Odometer
  - Oil Change Interval in km
  - Oil Change Range: Current Value In km
  - Oil Change Interval In Months
  - Oil Change Range: Current Value In Months

## Automatic Gearbox

- Advanced Function
  - Note Oil Wear Counter
  - Write Transmission Oil Change Date
  - Write Date of Last After Sales Operation
  - Auto Adaptives
  - Write VIN

- IPC(Instrument Panel Control)
- PAM(Park Aid Module)
- PDM(Passenger Door Module)
- PSCM(Power Steering Control Module)
- RACM(Rear Audio Control Module)
- RCM(Restraint Control Module)
- RGTM(Rear Gate/Trunk Module)
- RTM(Radio Transceiver Module)
- SCCM(Steering Column Control Module)
- SCM-E(Seat Control Module E)
- SCM-G(Seat Control Module G)
- SCM-H(Seat Control Module H)
- SOD-L(Side Obstacle Detection Control Module Left)
- SOD-R(Side Obstacle Detection Control Module Right)
- TRM(Trailer Module)
- VDM(Vehicle Dynamic Module)

**Feedback**

## Israel : MEGANE II

- Injection Actuation Test Function improved
- SRS Configuration Function improved

**FORD EU****Mondeo 2013~ 2.0L Duratorq-Turbo Diesel Common Rail Injection StgVI Vehicle Added**

- PCM(Powertrain Control Module)
- ABS(Anti-Lock Brake System)
- ACM(Audio Control Module)
- AHCM(Auxiliary Heater Control Module)
- APIM(Accessory Protocol Interface Module)
- BCMii(Body Control Module)
- CCMii(Cruise Control Module)
- DCDC(DC to DC Converter Control Module)
- DDM(Driver's Door Module)
- DSM(Driver Seat Module)
- DSP(Digital Signal Processing Module)
- FCIM(Front Controls Interface Module)
- FDSM(Front Distance Sensing Module)
- FCDIM(Front Control-Display Interface Module)
- GPSM(Global Positioning System Module)
- GWM(Gateway Module A)
- HCM(Headlamp Control Module)
- HSWM(Heated Steering Wheel Module)
- HUD(Head Up Display)
- IPM-A(Image Processing Module A)

For more information, please email [sales@e-zds.com](mailto:sales@e-zds.com), or call +82-70-7733-7811 or 7775

**GM USA****New Model & System added****- Chevrolet Passenger****F Product Line****-Powertrain**

3.6L LFX Engine Control Module Automatic Transmission  
3.6L LFX Engine Control Module Manual Transmission  
3.6L LFX Fuel Pump Control Module  
3.6L LFX Fuel Pump Version Fuel Pump  
3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow  
3.6L LFX Transmission Control Module  
3.6L LLT Engine Control Module Automatic Transmission  
3.6L LLT Engine Control Module Manual Transmission  
3.6L LLT Fuel Pump Control Module  
3.6L LLT Transmission Control Module  
6.2L L99 Engine Control Module Automatic Transmission  
6.2L L99 Engine Control Module Manual Transmission  
6.2L L99 Fuel Pump Control Module  
6.2L L99 Fuel Pump Version Fuel Pump  
6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow  
6.2L L99 Transmission Control Module  
6.2L LS3 Engine Control Module Automatic Transmission  
6.2L LS3 Engine Control Module Manual Transmission  
6.2L LS3 Fuel Pump Control Module  
6.2L LS3 Fuel Pump Version Fuel Pump  
6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow  
6.2L LS3 Transmission Control Module  
6.2L LSA Engine Control Module Automatic Transmission  
6.2L LSA Engine Control Module Manual Transmission  
6.2L LSA Fuel Pump Control Module  
6.2L LSA Fuel Pump Version Fuel Pump  
6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow  
6.2L LSA Transmission Control Module  
7.0L LS7 Engine Control Module Automatic Transmission  
7.0L LS7 Engine Control Module Manual Transmission  
Chassis Control Version Fuel Pump  
Chassis Control Version Fuel Pump and Exhaust Flow

**-Chassis**

Electronic Brake Control Module

Multi-Axis Acceleration Sensor Module  
Power Steering Control Module  
Steering Wheel Angle Sensor Module  
Suspension Control Module  
Parking Brake Control Module

**-Body**

Auxiliary Gage Module  
Body Control Module Headlamp Type Halogen (T4A TT4)  
Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)  
Folding Top Control Module  
Front Seat Heating Control Module  
Headlamp Control Module  
Head-Up Display Module  
HVAC Control Module  
Inflatable Restraint Sensing and Diagnostic Module  
Instrument Cluster  
Mobile Telephone Control Module  
Multimedia Player Interface Module  
Parking Assist Control Module  
Passenger Presence Module  
Radio  
Remote Heater and Air Conditioning Control Module  
Telematics Communication Interface Control Module Version 10  
Telematics Communication Interface Control Module Version 9  
Telematics Communication Interface Control Module Version 9.6  
Telematics Communication Interface Control Module Version 9.7  
Telematics Vehicle Localization and Immobilization Control Module

**J Product Line****-Powertrain**

1.2L LDC Chassis Control Module  
1.2L LDC Engine Control Module Automatic Transmission  
1.2L LDC Engine Control Module Manual Transmission  
1.2L LDC Fuel Pump Control Module  
1.2L LDC Transmission Control Module  
1.2L LMU Engine Control Module  
1.2L LWD Engine Control Module Automatic Transmission  
1.2L LWD Engine Control Module Manual Transmission  
1.2L LWD Transmission Control Module  
1.3L LDV Engine Control Module Automatic Transmission  
1.3L LDV Engine Control Module Manual Transmission  
1.3L LDV Transmission Control Module  
1.3L LSF Engine Control Module Automatic Transmission  
1.3L LSF Engine Control Module Manual Transmission

1.3L LSF Transmission Control Module  
1.4L L2N Engine Control Module Automatic Transmission  
1.4L L2N Engine Control Module Manual Transmission  
1.4L L2N Transmission Control Module  
1.4L L95 Engine Control Module  
1.4L L95 Transmission Control Module  
1.4L LDD Chassis Control Module  
1.4L LDD Engine Control Module Automatic Transmission  
1.4L LDD Engine Control Module Manual Transmission  
1.4L LDD Fuel Pump Control Module  
1.4L LDD Transmission Control Module  
1.4L LDT Engine Control Module Automatic Transmission  
1.4L LDT Engine Control Module Manual Transmission  
1.4L LDT Transmission Control Module  
1.4L LUJ Chassis Control Module  
1.4L LUJ Engine Control Module Automatic Transmission  
1.4L LUJ Engine Control Module Manual Transmission  
1.4L LUJ Transmission Control Module  
1.4L LUV Chassis Control Module  
1.4L LUV Engine Control Module Automatic Transmission  
1.4L LUV Engine Control Module Manual Transmission  
1.4L LUV Fuel Pump Control Module  
1.4L LUV Transmission Control Module  
1.5L LV8 Engine Control Module  
1.5L LV8 Transmission Control Module  
1.6L LDE Chassis Control Module  
1.6L LDE Engine Control Module Automatic Transmission  
1.6L LDE Engine Control Module Manual Transmission  
1.6L LDE Fuel Pump Control Module  
1.6L LDE Transmission Control Module  
1.6L LED Engine Control Module Automatic Transmission  
1.6L LED Engine Control Module Manual Transmission  
1.6L LED Transmission Control Module  
1.6L LFJ Engine Control Module Automatic Transmission  
1.6L LFJ Engine Control Module Manual Transmission  
1.6L LFJ Transmission Control Module  
1.6L LXT Engine Control Module  
1.6L LXT Transmission Control Module  
1.8L LUW Chassis Control Module  
1.8L LUW Engine Control Module Automatic Transmission  
1.8L LUW Engine Control Module Manual Transmission  
1.8L LUW Fuel Pump Control Module  
1.8L LUW Transmission Control Module  
1.8L LWE Chassis Control Module  
1.8L LWE Engine Control Module Automatic Transmission

1.8L LWE Engine Control Module Manual Transmission  
1.8L LWE Fuel Pump Control Module  
1.8L LWE Transmission Control Module  
Chassis Control Module  
Fuel Injector Control Module  
Fuel Pump Control Module

-Chassis  
Electric Power Steering Control Module  
Electronic Brake Control Module  
Fuel Pump Control Module  
Multi-Axis Acceleration Sensor Module  
Power Steering Control Module  
Steering Wheel Angle Sensor Module  
Steering Wheel Angle Sensor Module Chassis  
Expansion CAN BUS  
Steering Wheel Angle Sensor Module High Speed CAN Bus

-Body  
Body Control Module Hatchback  
Body Control Module Sedan  
Passenger Presence Module  
Instrument Cluster  
Radio  
Telematic Vehicle Localization and Immobilization Control Module  
HVAC Control Module Heater Only (C41)  
HVAC Control Module Air Conditioning Only (C7B)  
HVAC Control Module Single Zone (C60)  
Front Seat Heating Control Module  
Parking Assist Control Module  
Telematics Communication Interface Control Module 9  
Telematics Communication Interface Control Module 10  
Inflatable Restraint Sensing and Diagnostic Module  
Telematics Communication Interface Control Module  
Keyless Entry Control Module  
Frontview Camera Module

**N Product Line**

-Powertrain  
3.6L LFX Engine Control Module Automatic Transmission  
3.6L LFX Engine Control Module Manual Transmission  
3.6L LFX Transmission Control Module  
6.0L L77 Engine Control Module Automatic Transmission  
6.0L L77 Engine Control Module Manual Transmission  
6.0L L77 Chassis Control Module  
6.0L L77 Transmission Control Module  
Fuel Injector Control Module

-Chassis  
Electronic Brake Control Module  
Parking Brake Control Module

Power Steering Control Module  
Steering Wheel Angle Sensor Module  
Suspension Control Module

-Body  
Body Control Module  
Inflatable Restraint Sensing and Diagnostic Module  
Passenger Presence Module  
Instrument Cluster  
Radio Controls  
HVAC Controls  
Headlamp Control Module  
Trailer Interface Control Module  
Radio  
HVAC Control Module  
Parking Assist Control Module  
Frontview Camera Module  
Steering Column Lock Control Module  
Head-Up Display Module  
Telematics Communication Interface Control Module  
Right Side Object Detection Control Module  
Left Side Object Detection Control Module

**S Product Line**

-Powertrain  
1.2L LDC Engine Control Module Automatic Transmission  
1.2L LDC Engine Control Module Manual Transmission  
1.2L LDC Transmission Control Module  
1.2L LMU Engine Control Module  
1.2L LWD Engine Control Module Automatic Transmission  
1.2L LWD Engine Control Module Manual Transmission  
1.2L LWD Transmission Control Module  
1.3L LDV Engine Control Module Automatic Transmission  
1.3L LDV Engine Control Module Manual Transmission  
1.3L LDV Transmission Control Module  
1.3L LSF Engine Control Module Automatic Transmission  
1.3L LSF Engine Control Module Manual Transmission  
1.3L LSF Transmission Control Module  
1.4L L2N Engine Control Module Automatic Transmission  
1.4L L2N Engine Control Module Manual Transmission  
1.4L L2N Transmission Control Module  
1.4L L95 Engine Control Module  
1.4L L95 Transmission Control Module  
1.4L LDD Engine Control Module Automatic Transmission  
1.4L LDD Engine Control Module Manual Transmission  
1.4L LDD Transmission Control Module  
1.4L LDT Engine Control Module Automatic Transmission  
1.4L LDT Engine Control Module Manual Transmission

1.4L LDT Transmission Control Module  
1.4L LUJ Engine Control Module Automatic Transmission  
1.4L LUJ Engine Control Module Manual Transmission  
1.4L LUJ Transmission Control Module  
1.4L LUV Engine Control Module Automatic Transmission  
1.4L LUV Engine Control Module Manual Transmission  
1.4L LUV Transmission Control Module  
1.5L LV8 Engine Control Module  
1.5L LV8 Transmission Control Module  
1.6L LDE Engine Control Module Automatic Transmission  
1.6L LDE Engine Control Module Manual Transmission  
1.6L LDE Transmission Control Module  
1.6L LED Engine Control Module Automatic Transmission  
1.6L LED Engine Control Module Manual Transmission  
1.6L LED Transmission Control Module  
1.6L LFJ Engine Control Module Automatic Transmission  
1.6L LFJ Engine Control Module Manual Transmission  
1.6L LFJ Transmission Control Module  
1.6L LXT Engine Control Module  
1.6L LXT Transmission Control Module  
1.8L LUW Engine Control Module Automatic Transmission  
1.8L LUW Engine Control Module Manual Transmission  
1.8L LUW Transmission Control Module  
Chassis Control Module  
Fuel Injector Control Module  
Fuel Pump Control Module

-Chassis  
Electronic Brake Control Module  
Multi-Axis Acceleration Sensor Module  
Electric Power Steering Control Module  
Steering Wheel Angle Sensor Module  
Power Steering Control Module  
Fuel Pump Control Module

-Body  
Body Control Module Hatchback  
Body Control Module Sedan  
Passenger Presence Module  
Instrument Cluster  
Radio  
Telematic Vehicle Localization and Immobilization Control Module  
HVAC Control Module Heater Only (C41)  
HVAC Control Module Air Conditioning Only (C7B)  
HVAC Control Module Single Zone (C60)  
Front Seat Heating Control Module  
Parking Assist Control Module  
Inflatable Restraint Sensing and Diagnostic Module

Telematics Communication Interface Control Module  
Keyless Entry Control Module

**T Product Line**

-Powertrain

1.2L LDC Engine Control Module Automatic Transmission  
1.2L LDC Engine Control Module Manual Transmission  
1.2L LDC Transmission Control Module  
1.2L LMU Engine Control Module  
1.2L LWD Engine Control Module Automatic Transmission  
1.2L LWD Engine Control Module Manual Transmission  
1.2L LWD Transmission Control Module  
1.3L LDV Engine Control Module Automatic Transmission  
1.3L LDV Engine Control Module Manual Transmission  
1.3L LDV Transmission Control Module  
1.3L LSF Engine Control Module Automatic Transmission  
1.3L LSF Engine Control Module Manual Transmission  
1.3L LSF Transmission Control Module  
1.4L L2N Engine Control Module Automatic Transmission  
1.4L L2N Engine Control Module Manual Transmission  
1.4L L2N Transmission Control Module  
1.4L L95 Engine Control Module  
1.4L L95 Transmission Control Module  
1.4L LDD Engine Control Module Automatic Transmission  
1.4L LDD Engine Control Module Manual Transmission  
1.4L LDD Transmission Control Module  
1.4L LDT Engine Control Module Automatic Transmission  
1.4L LDT Engine Control Module Manual Transmission  
1.4L LDT Transmission Control Module  
1.4L LUJ Engine Control Module Automatic Transmission  
1.4L LUJ Engine Control Module Manual Transmission  
1.4L LUJ Transmission Control Module  
1.4L LUV Engine Control Module Automatic Transmission  
1.4L LUV Engine Control Module Manual Transmission  
1.4L LUV Transmission Control Module  
1.5L LV8 Engine Control Module  
1.5L LV8 Transmission Control Module  
1.6L LDE Engine Control Module Automatic Transmission  
1.6L LDE Engine Control Module Manual Transmission  
1.6L LDE Transmission Control Module  
1.6L LED Engine Control Module Automatic Transmission  
1.6L LED Engine Control Module Manual Transmission  
1.6L LED Transmission Control Module  
1.6L LFJ Engine Control Module Automatic

Transmission

1.6L LFJ Engine Control Module Manual Transmission  
1.6L LFJ Transmission Control Module  
1.6L LXT Engine Control Module  
1.6L LXT Transmission Control Module  
1.8L LUW Engine Control Module Automatic Transmission  
1.8L LUW Engine Control Module Manual Transmission  
1.8L LUW Transmission Control Module  
Chassis Control Module  
Fuel Injector Control Module  
Fuel Pump Control Module

-Chassis

Electronic Brake Control Module  
Multi-Axis Acceleration Sensor Module  
Electric Power Steering Control Module  
Steering Wheel Angle Sensor Module  
Power Steering Control Module  
Fuel Pump Control Module

-Body

Body Control Module Hatchback  
Body Control Module Sedan  
Passenger Presence Module  
Instrument Cluster  
Radio  
Telematic Vehicle Localization and Immobilization Control Module  
HVAC Control Module Heater Only (C41)  
HVAC Control Module Air Conditioning Only (C7B)  
HVAC Control Module Single Zone (C60)  
Front Seat Heating Control Module  
Parking Assist Control Module  
Inflatable Restraint Sensing and Diagnostic Module  
Telematics Communication Interface Control Module  
Keyless Entry Control Module

**W Product Line**

-Powertrain

3.6L LFX Engine Control Module  
3.6L LFX Transmission Control Module  
3.6L LFX Chassis Control Module

-Chassis

Electronic Brake Control Module

-Body

Body Control Module  
Inflatable Restraint Sensing and Diagnostic Module  
Passenger Presence Module  
Instrument Cluster  
Radio  
Digital Radio Receiver Control Module  
Telematics Communication Interface Version 9



Telematics Communication Interface Version 10  
HVAC Auto Control Dual Zone (CJ2)  
HVAC Manual Control Single Zone (C67)  
Front Seat Heating Control Module  
Remote Control Door Lock Receiver  
Theft Deterrent Module

**Z Product Line**

-Powertrain  
2.0L LBN Engine Control Module Automatic Transmission  
2.0L LBN Engine Control Module Manual Transmission  
2.0L LBN Fuel Injector Control Module  
2.0L LBN Transmission Control Module  
2.0L LBS Engine Control Module Automatic Transmission  
2.0L LBS Engine Control Module Manual Transmission  
2.0L LBS Transmission Control Module  
2.0L LTD Engine Control Module Automatic Transmission  
2.0L LTD Engine Control Module Manual Transmission  
2.0L LTD Fuel Pump Control Module  
2.0L LTD Transmission Control Module  
2.4L LE9 Engine Control Module Automatic Transmission  
2.4L LE9 Engine Control Module Manual Transmission  
2.4L LE9 Fuel Pump Control Module  
2.4L LE9 Transmission Control Module  
3.0L LFW Engine Control Module Automatic Transmission  
3.0L LFW Engine Control Module Manual Transmission  
3.0L LFW Transmission Control Module  
Rear Differential Clutch Control Module

**-Chassis**

Electronic Brake Control Module  
Parking Brake Control Module  
Multi-Axis Acceleration Sensor Module  
Power Steering Control Module  
Steering Wheel Angle Sensor Module  
Suspension Control Module

**-Body**

Body Control Module Headlamp Type Halogen (T4A TT4)  
Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)  
Inflatable Restraint Sensing and Diagnostic Module Version 3  
Inflatable Restraint Sensing and Diagnostic Module Version 4  
Passenger Presence Module  
Instrument Cluster  
Head-Up Display Module  
Headlamp Control Module  
Radio

Digital Radio Receiver Control Module  
Multimedia Player Interface Module  
Mobile Telephone Control Module  
HVAC Control Module Auto Dual (CJ2)  
HVAC Control Module Auto Single (C68)  
HVAC Control Module Manual Single (C67)  
Rear Seat Heating Control Module  
Keyless Entry Control Module  
Right Side Object Detection Control Module  
Left Side Object Detection Control Module  
Parking Assist Control Module  
Vehicle Direction Camera Control Module  
Steering Column Lock Control Module

**1 Product Line**

-Powertrain  
1.6L LLU Engine Control Module  
2.0L LBN Chassis Control Module  
2.0L LBN Engine Control Module Automatic Transmission  
2.0L LBN Engine Control Module Manual Transmission  
2.0L LBN Fuel Injector Control Module  
2.0L LBN Transmission Control Module  
2.0L LBS Chassis Control Module  
2.0L LBS Engine Control Module Automatic Transmission  
2.0L LBS Engine Control Module Manual Transmission  
2.0L LBS Transmission Control Module  
2.0L LBY Engine Control Module Automatic Transmission  
2.0L LBY Engine Control Module Manual Transmission  
2.0L LTD Chassis Control Module  
2.0L LTD Engine Control Module Automatic Transmission  
2.0L LTD Engine Control Module Manual Transmission  
2.0L LTD Fuel Pump Control Module  
2.0L LTD Transmission Control Module  
2.0L LTG Chassis Control Module  
2.0L LTG Engine Control Module Automatic Transmission  
2.0L LTG Engine Control Module Manual Transmission  
2.0L LTG Fuel Pump Control Module  
2.0L LTG Transmission Control Module  
2.4L LE9 Chassis Control Module  
2.4L LE9 Engine Control Module Automatic Transmission  
2.4L LE9 Engine Control Module Manual Transmission  
2.4L LE9 Transmission Control Module  
2.4L LUK Chassis Control Module  
2.4L LUK Drive Motor Control Module  
2.4L LUK Engine Control Module  
2.4L LUK Fuel Pump Control Module  
2.4L LUK Hybrid Powertrain Control Module  
2.4L LUK Transmission Control Module  
2.5L LCV Engine Control Module Automatic

**Transmission**

2.5L LCV Engine Control Module Manual Transmission  
2.5L LCV Fuel Pump Control Module  
2.5L LCV Transmission Control Module  
2.5L LKW Chassis Control Module  
2.5L LKW Engine Control Module  
2.5L LKW Engine Control Module Automatic Transmission  
2.5L LKW Engine Control Module Manual Transmission  
2.5L LKW Transmission Control Module  
3.0L LFW Chassis Control Module  
3.0L LFW Engine Control Module Automatic Transmission  
3.0L LFW Engine Control Module Manual Transmission  
3.0L LFW Transmission Control Module  
3.6L LFR Engine Control Module  
3.6L LFR Transmission Control Module  
3.6L LFX Engine Control Module  
3.6L LFX Transmission Control Module  
Chassis Control Module Version Fuel Pump  
Chassis Control Module Version Fuel Pump and Active Grille Air Shutter  
Rear Differential Clutch Control Module  
Transmission Control Module

**-Chassis**

Electronic Brake Control Module  
Parking Brake Control Module  
Multi-Axis Acceleration Sensor Module  
Power Steering Control Module  
Steering Wheel Angle Sensor Module  
Suspension Control Module  
Distance Sensing Cruise Control Module

**-Body**

Body Control Module Headlamp Type Halogen (T4A TT4)  
Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)  
Inflatable Restraint Sensing and Diagnostic Module Version 3  
Inflatable Restraint Sensing and Diagnostic Module Version 4  
Passenger Presence Module  
Instrument Cluster  
Headlamp Control Module  
Radio  
Digital Radio Receiver Control Module  
Multimedia Player Interface Module  
Mobile Telephone Control Module  
Telematics Communication Interface Version 9  
Telematics Communication Interface Version 10  
HVAC Control Module Auto Dual (CJ2)  
HVAC Control Module Auto Single (C68)  
HVAC Control Module Manual Single (C67)  
Rear Seat Heating Control Module

**Keyless Entry Control Module**

Parking Assist Control Module  
Vehicle Direction Camera Control Module  
Steering Column Lock Control Module  
Battery Energy Control Module  
Inflatable Restraint Sensing and Diagnostic Module  
Radio Control  
HVAC Control  
Amplifier  
Human Machine Interface Control Module  
Telematics Communication Interface Control Module Version 9  
Telematics Communication Interface Control Module Version 10  
HVAC Control Module  
Right Side Object Detection Control Module  
Left Side Object Detection Control Module  
Frontview Camera Module  
HVAC Control Module Semi Auto Single (C4P)  
Telematics Communication Interface Control Module  
Telematics Communication Interface Control Module Version 9.7  
Front Seat Heating Control Module

**Beat****-Powertrain**

1.0L LEB Engine Control Module  
1.0L LEB Engine Control Module Automatic Transmission  
1.0L LEB Engine Control Module Manual Transmission  
1.19L LC5 Engine Control Module  
Fuel Injector Control Module  
Transmission Control Module

**-Chassis**

Electronic Brake Control Module  
Multi-Axis Acceleration Sensor Module  
Power Steering Control Module  
Steering Wheel Angle Sensor Module  
Electric Power Steering Control Module

**-Body**

Inflatable Restraint Sensing and Diagnostic Module  
Instrument Cluster  
Keyless Entry Control Module  
Telematics Communication Interface Control Module  
Radio

**- Chevrolet LD Trk/MPV/Incomplete C Product Line****-Powertrain**

4.3L LV1 Engine Control Module  
4.3L LV3 Engine Control Module  
4.3L LV3 Transmission Control Module  
5.3L L83 Engine Control Module

5.3L L83 Transmission Control Module  
5.3L LC9 Engine Control Module  
5.3L LC9 Transmission Control Module  
5.3L LFT Transmission Control Module  
5.3L LMG Engine Control Module  
5.3L LMG Transmission Control Module  
6.0L L96 Engine Control Module  
6.0L L96 Fuel Injector Control Module  
6.0L L96 Transmission Control Module  
6.0L LC8 Engine Control Module  
6.0L LC8 Fuel Injector Control Module  
6.0L LC8 Transmission Control Module  
6.2L L86 Engine Control Module  
6.2L L86 Transmission Control Module  
6.2L L86 Transmission Control Module 6 Speed  
6.2L L86 Transmission Control Module 8 Speed  
6.6L LML Engine Control Module  
6.6L LML Glow Plug Control Module  
6.6L LML Power Take-Off Control Module  
6.6L LML Transmission Control Module  
6.6L LML Transmission Control Module My 2015 (WMF)  
6.6L LML Transmission Control Module My 2015.5 (AVF)  
Auxiliary Transmission Fluid Pump  
Chassis Control Version Active Grille Air Shutter  
Chassis Control Version Fuel Pump  
Chassis Control Version Fuel Pump and Trailer Brake Control  
Chassis Control Version Trailer Brake Control  
Chassis Control Version Trailer Brake Control and Automatic Level Control  
Drive Motor Control Module 1  
Drive Motor Control Module 2  
Transfer Case Control Module  
Transfer Case Version Single Speed Switch Activated (NP0)  
Transfer Case Version Two Speed Electric Shift (NQF)  
Transfer Case Version Two Speed Manual Shift (NQG)  
Transfer Case Version Two Speed Switch Activated (NQH)  
Transfer Case Version Two Wheel Drive

**-Chassis**

Electronic Brake Control Module  
Parking Brake Control Module  
Power Steering Control Module  
Steering Wheel Angle Sensor Module  
Trailer Brake Control Module  
Suspension Control Module  
Distance Sensing Cruise Control Module  
Multi-Axis Acceleration Sensor Module

**-Body**

Amplifier  
Assist Step Control Module  
Auxiliary Body Control Module

Base Radio  
Battery Energy Control Module  
Body Control Module  
Chime Alarm Control Module  
Digital Radio Receiver Control Module  
Driver Door Switch Panel Control Module  
Frontview Camera Module  
Human Machine Interface Control Module  
HVAC Auto Control Dual Zone (CJ2)  
HVAC Control  
HVAC Manual Control Dual Zone (CJ3)  
HVAC Manual Control Heater Only (C42)  
HVAC Manual Control Single Zone (C67)  
Inflatable Restraint Sensing and Diagnostic Module  
Instrument Cluster  
Keyless Entry Control Module  
Left Side Object Detection Control Module  
Liftgate Control Module  
Media Disc Player  
Navigation Radio  
Parking Assist Control Module  
Passenger Door Switch Panel Control Module  
Passenger Presence Module  
Personal Audio Link Control Module  
Radio  
Radio Control  
Rear Audio Control Module  
Rear Seat Heating Control Module  
Remote Control Door Lock Receiver  
Right Side Object Detection Control Module  
Seat Memory Control Module  
Steering Column Lock Control Module  
Telematics Communication Interface Control Module  
Telematics Communication Interface Control Module Version 10  
Telematics Communication Interface Control Module Version 9  
Telematics Communication Interface Control Module Version 9.6  
Telematics Communication Interface Control Module Version 9.7  
Theft Deterrent Module

**G Product Line****-Powertrain**

4.3L LU3 Engine Control Module  
4.3L LU3 Transmission Control Module  
4.8L L20 Engine Control Module  
4.8L L20 Transmission Control Module  
5.3L LMF Engine Control Module  
5.3L LMF Chassis Control Module  
5.3L LMF Transmission Control Module  
6.0L L96 Engine Control Module  
6.0L L96 Transmission Control Module  
6.0L LC8 Engine Control Module

6.0L LC8 Transmission Control Module  
6.6L LGH Engine Control Module  
6.6L LGH Glow Plug Control Module  
6.6L LGH Transmission Control Module

-Chassis

Electronic Brake Control Module

-Body

Body Control Module  
Inflatable Restraint Sensing and Diagnostic Module  
Passenger Presence Module  
Rollover Sensor Module  
Instrument Cluster  
Chime Alarm Control Module  
Base Radio  
Navigation Radio  
Uplevel Radio  
Digital Radio Receiver Control Module  
Telematics Communication Interface Version 9  
Telematics Communication Interface Version 10  
Auxiliary Heater Control Module  
Remote Control Door Lock Receiver  
Parking Assist Control Module  
Theft Deterrent Module

**H Product Line**

-Powertrain

4.3L LU3 Engine Control Module  
4.3L LU3 Transmission Control Module  
4.8L L20 Engine Control Module  
4.8L L20 Transmission Control Module  
5.3L LMF Engine Control Module  
5.3L LMF Chassis Control Module  
5.3L LMF Transmission Control Module  
6.0L L96 Engine Control Module  
6.0L L96 Transmission Control Module  
6.0L LC8 Engine Control Module  
6.0L LC8 Transmission Control Module  
6.6L LGH Engine Control Module  
6.6L LGH Glow Plug Control Module  
6.6L LGH Transmission Control Module

-Chassis

Electronic Brake Control Module

-Body

Body Control Module  
Inflatable Restraint Sensing and Diagnostic Module  
Passenger Presence Module  
Rollover Sensor Module  
Instrument Cluster  
Chime Alarm Control Module  
Base Radio  
Navigation Radio

Uplevel Radio

Digital Radio Receiver Control Module  
Telematics Communication Interface Version 9  
Telematics Communication Interface Version 10  
Auxiliary Heater Control Module  
Remote Control Door Lock Receiver  
Parking Assist Control Module  
Theft Deterrent Module

**K Product Line**

-Powertrain

4.3L LV1 Engine Control Module  
4.3L LV3 Engine Control Module  
4.3L LV3 Transmission Control Module  
5.3L L83 Engine Control Module  
5.3L L83 Transmission Control Module  
5.3L LC9 Engine Control Module  
5.3L LC9 Transmission Control Module  
5.3L LFT Transmission Control Module  
5.3L LMG Engine Control Module  
5.3L LMG Transmission Control Module  
6.0L L96 Engine Control Module  
6.0L L96 Fuel Injector Control Module  
6.0L L96 Transmission Control Module  
6.0L LC8 Engine Control Module  
6.0L LC8 Fuel Injector Control Module  
6.0L LC8 Transmission Control Module  
6.2L L86 Engine Control Module  
6.2L L86 Transmission Control Module  
6.2L L86 Transmission Control Module 6 Speed  
6.2L L86 Transmission Control Module 8 Speed  
6.6L LML Engine Control Module  
6.6L LML Glow Plug Control Module  
6.6L LML Power Take-Off Control Module  
6.6L LML Transmission Control Module  
6.6L LML Transmission Control Module My 2015 (WMF)  
6.6L LML Transmission Control Module My 2015.5 (AVF)  
Auxiliary Transmission Fluid Pump  
Chassis Control Version Active Grille Air Shutter  
Chassis Control Version Fuel Pump  
Chassis Control Version Fuel Pump and Trailer Brake Control  
Chassis Control Version Trailer Brake Control  
Chassis Control Version Trailer Brake Control and Automatic Level Control  
Drive Motor Control Module 1  
Drive Motor Control Module 2  
Transfer Case Control Module  
Transfer Case Version Single Speed Switch Activated (NP0)  
Transfer Case Version Two Speed Electric Shift (NQF)  
Transfer Case Version Two Speed Manual Shift (NQG)  
Transfer Case Version Two Speed Switch Activated (NQH)  
Transfer Case Version Two Wheel Drive

**-Chassis**

Electronic Brake Control Module  
 Parking Brake Control Module  
 Power Steering Control Module  
 Steering Wheel Angle Sensor Module  
 Trailer Brake Control Module  
 Suspension Control Module  
 Distance Sensing Cruise Control Module  
 Multi-Axis Acceleration Sensor Module

**-Body**

Amplifier  
 Assist Step Control Module  
 Auxiliary Body Control Module  
 Base Radio  
 Battery Energy Control Module  
 Body Control Module  
 Chime Alarm Control Module  
 Digital Radio Receiver Control Module  
 Driver Door Switch Panel Control Module  
 Frontview Camera Module  
 Human Machine Interface Control Module  
 HVAC Auto Control Dual Zone (CJ2)  
 HVAC Control  
 HVAC Manual Control Dual Zone (CJ3)  
 HVAC Manual Control Heater Only (C42)  
 HVAC Manual Control Single Zone (C67)  
 Inflatable Restraint Sensing and Diagnostic Module  
 Instrument Cluster  
 Keyless Entry Control Module  
 Left Side Object Detection Control Module  
 Liftgate Control Module  
 Media Disc Player  
 Navigation Radio  
 Parking Assist Control Module  
 Passenger Door Switch Panel Control Module  
 Passenger Presence Module  
 Personal Audio Link Control Module  
 Radio  
 Radio Control  
 Rear Audio Control Module  
 Rear Seat Heating Control Module  
 Remote Control Door Lock Receiver  
 Right Side Object Detection Control Module  
 Seat Memory Control Module  
 Steering Column Lock Control Module  
 Telematics Communication Interface Control Module  
 Telematics Communication Interface Control Module  
 Version 10  
 Telematics Communication Interface Control Module  
 Version 9  
 Telematics Communication Interface Control Module  
 Version 9.6  
 Telematics Communication Interface Control Module

**Version 9.7**

Theft Deterrent Module

**L Product Line**
**-Powertrain**

2.0L LNP Engine Control Module Automatic  
 Transmission  
 2.0L LNP Engine Control Module Manual Transmission  
 2.0L LNP Transmission Control Module  
 2.0L LNQ Engine Control Module Automatic  
 Transmission  
 2.0L LNQ Engine Control Module Manual Transmission  
 2.2L LNQ Transmission Control Module  
 2.4L LAF Engine Control Module  
 2.4L LAF Transmission Control Module  
 2.4L LE5 Engine Control Module Automatic  
 Transmission  
 2.4L LE5 Engine Control Module Manual Transmission  
 2.4L LE5 Fuel Pump Control Module  
 2.4L LE5 Transmission Control Module  
 2.4L LE9 Engine Control Module Automatic  
 Transmission  
 2.4L LE9 Engine Control Module Manual Transmission  
 2.4L LE9 Fuel Pump Control Module  
 2.4L LE9 Transmission Control Module  
 2.4L LEA Engine Control Module  
 2.4L LEA Engine Control Module Automatic  
 Transmission  
 2.4L LEA Engine Control Module Manual Transmission  
 2.4L LEA Transmission Control Module  
 3.0L LF1 Engine Control Module  
 3.0L LF1 Engine Control Module Automatic  
 Transmission  
 3.0L LF1 Engine Control Module Manual Transmission  
 3.0L LF1 Fuel Pump Control Module  
 3.0L LF1 Transmission Control Module  
 3.0L LFW Engine Control Module  
 3.0L LFW Engine Control Module Automatic  
 Transmission  
 3.0L LFW Engine Control Module Manual Transmission  
 3.0L LFW Fuel Pump Control Module  
 3.0L LFW Transmission Control Module  
 3.6L LFX Engine Control Module  
 3.6L LFX Transmission Control Module  
 Chassis Control Module  
 Fuel Pump Control Module  
 Rear Differential Clutch Control Module

**-Chassis**

Electronic Brake Control Module  
 Multi-Axis Acceleration Sensor Module  
 Steering Wheel Angle Sensor Module  
 Parking Brake Control Module  
 Power Steering Control Module

**-Body**

Auxiliary Body Control Module  
Body Control Module HVAC Module Type Auto  
Body Control Module HVAC Module Type Manual  
Body Control Module Mechanical Liftgate  
Body Control Module Power Liftgate (TB5)  
Digital Radio Receiver Control Module  
Front Seat Heating Control Module  
Frontview Camera Module  
Headlamp Control Module  
HVAC Control Module Auto Single (C68)  
HVAC Control Module Manual Single (C67)  
Inflatable Restraint Sensing and Diagnostic Module  
Instrument Cluster  
Left Side Object Detection Control Module  
Liftgate Control Module  
Multimedia Player Interface Module  
Parking Assist Control Module  
Passenger Presence Module  
Radio  
Rear Audio Control Module  
Remote Control Keyless Type Extended Range Passive Entry (ATH)  
Remote Control Keyless Type Standard Range (ATG)  
Right Side Object Detection Control Module  
Telematic Vehicle Localization and Immobilization Control Module  
Telematics Communication Interface Control Module 10  
Telematics Communication Interface Control Module 9  
Theft Deterrent Module  
Vehicle Direction Camera Control Module

**R Product Line****-Powertrain**

3.6L LLT Engine Control Module  
3.6L LLT Transmission Control Module  
Chassis Control Module  
Rear Differential Clutch Control Module

**-Chassis**

Electronic Brake Control Module

**-Body**

Body Control Module Mechanical Liftgate  
Body Control Module Power Liftgate (TB5)  
Inflatable Restraint Sensing and Diagnostic Module  
Passenger Presence Module  
Instrument Cluster  
Radio  
Rear Audio Control Module  
Digital Radio Receiver Control Module  
Personal Audio Link Control Module  
Telematics Communication Interface Version 9  
Telematics Communication Interface Version 10  
HVAC Auto Control Dual Zone (CJ2)

HVAC Manual Control Single Zone (C67)  
Driver Door Switch Panel Control Module  
Passenger Door Switch Panel Control Module  
Liftgate Control Module  
Seat Memory Control Module  
Front Seat Heating Control Module  
Right Side Object Detection Control Module  
Left Side Object Detection Control Module  
Remote Control Door Lock Receiver  
Parking Assist Control Module  
Frontview Camera Module  
Theft Deterrent Module

**S Product Line****-Powertrain**

2.4L LE6 Engine Control Module Automatic Transmission  
2.4L LE6 Engine Control Module Manual Transmission  
2.5L LCV Engine Control Module Automatic Transmission  
2.5L LCV Engine Control Module Manual Transmission  
2.5L LCV Transmission Control Module  
2.5L LKH Engine Control Module Automatic Transmission  
2.5L LKH Engine Control Module Manual Transmission  
2.5L LVN Engine Control Module Automatic Transmission  
2.5L LVN Engine Control Module Manual Transmission  
2.8L LWH Engine Control Module Automatic Transmission  
2.8L LWH Engine Control Module Manual Transmission  
2.8L LWH Transmission Control Module  
2.8L LWN Engine Control Module Automatic Transmission  
2.8L LWN Engine Control Module Manual Transmission  
2.8L LWN Transmission Control Module  
3.6L LFX Engine Control Module Automatic Transmission  
3.6L LFX Engine Control Module Manual Transmission  
3.6L LFX Transmission Control Module  
3.6L LY7 Engine Control Module Automatic Transmission  
3.6L LY7 Engine Control Module Manual Transmission  
3.6L LY7 Transmission Control Module  
Chassis Control Module  
Transfer Case Control Module

**-Chassis**

Electronic Brake Control Module  
Multi-Axis Acceleration Sensor Module  
Steering Wheel Angle Sensor Module  
Power Steering Control Module

**-Body**

Body Control Module



Inflatable Restraint Sensing and Diagnostic Module  
Instrument Cluster  
Trailer Interface Control Module  
Parking Assist Control Module  
Radio  
Telematics Communication Interface Control Module  
Passenger Presence Module  
Amplifier  
Human Machine Interface Control Module  
HVAC Control Module Auto Single (C68)  
HVAC Control Module Manual Single (C67)  
Frontview Camera Module

### T Product Line

-Powertrain  
2.4L LE6 Engine Control Module Automatic Transmission  
2.4L LE6 Engine Control Module Manual Transmission  
2.5L LCV Engine Control Module Automatic Transmission  
2.5L LCV Engine Control Module Manual Transmission  
2.5L LCV Transmission Control Module  
2.5L LKH Engine Control Module Automatic Transmission  
2.5L LKH Engine Control Module Manual Transmission  
2.5L LVN Engine Control Module Automatic Transmission  
2.5L LVN Engine Control Module Manual Transmission  
2.8L LWH Engine Control Module Automatic Transmission  
2.8L LWH Engine Control Module Manual Transmission  
2.8L LWH Transmission Control Module  
2.8L LWN Engine Control Module Automatic Transmission  
2.8L LWN Engine Control Module Manual Transmission  
2.8L LWN Transmission Control Module  
3.6L LFX Engine Control Module Automatic Transmission  
3.6L LFX Engine Control Module Manual Transmission  
3.6L LFX Transmission Control Module  
3.6L LY7 Engine Control Module Automatic Transmission  
3.6L LY7 Engine Control Module Manual Transmission  
3.6L LY7 Transmission Control Module  
Chassis Control Module  
Transfer Case Control Module

#### -Chassis

Electronic Brake Control Module  
Multi-Axis Acceleration Sensor Module  
Steering Wheel Angle Sensor Module  
Power Steering Control Module

#### -Body

Body Control Module

Inflatable Restraint Sensing and Diagnostic Module  
Instrument Cluster  
Trailer Interface Control Module  
Parking Assist Control Module  
Radio  
Telematics Communication Interface Control Module  
Passenger Presence Module  
Amplifier  
Human Machine Interface Control Module  
HVAC Control Module Auto Single (C68)  
HVAC Control Module Manual Single (C67)  
Frontview Camera Module

### V Product Line

-Powertrain  
3.6L LLT Engine Control Module  
3.6L LLT Transmission Control Module  
Chassis Control Module  
Rear Differential Clutch Control Module

#### -Chassis

Electronic Brake Control Module

#### -Body

Body Control Module Mechanical Liftgate  
Body Control Module Power Liftgate (TB5)  
Inflatable Restraint Sensing and Diagnostic Module  
Passenger Presence Module  
Instrument Cluster  
Radio  
Rear Audio Control Module  
Digital Radio Receiver Control Module  
Personal Audio Link Control Module  
Telematics Communication Interface Version 9  
Telematics Communication Interface Version 10  
HVAC Auto Control Dual Zone (CJ2)  
HVAC Manual Control Single Zone (C67)  
Driver Door Switch Panel Control Module  
Passenger Door Switch Panel Control Module  
Liftgate Control Module  
Seat Memory Control Module  
Front Seat Heating Control Module  
Right Side Object Detection Control Module  
Left Side Object Detection Control Module  
Remote Control Door Lock Receiver  
Parking Assist Control Module  
Frontview Camera Module  
Theft Deterrent Module

### - GMC LD Trk/MPV/Incomplete

#### L Product Line

-Powertrain  
2.4L LAF Engine Control Module  
2.4L LAF Transmission Control Module  
2.4L LEA Engine Control Module

For more information, please email [sales@e-zds.com](mailto:sales@e-zds.com), or call +82-70-7733-7811 or 7775

2.4L LEA Transmission Control Module  
3.0L LF1 Engine Control Module  
3.0L LF1 Transmission Control Module  
3.0L LFW Engine Control Module  
3.0L LFW Transmission Control Module  
3.6L LFX Engine Control Module  
3.6L LFX Transmission Control Module  
Fuel Pump Control Module  
Rear Differential Clutch Control Module

-Chassis

Electronic Brake Control Module  
Multi-Axis Acceleration Sensor Module  
Steering Wheel Angle Sensor Module  
Power Steering Control Module

-Body

Body Control Module Mechanical Liftgate  
Body Control Module Power Liftgate (TB5)  
Frontview Camera Module  
HVAC Control Module Auto Single (C68)  
HVAC Control Module Manual Single (C67)  
Inflatable Restraint Sensing and Diagnostic Module  
Instrument Cluster  
Left Side Object Detection Control Module  
Liftgate Control Module  
Multimedia Player Interface Module  
Parking Assist Control Module  
Passenger Presence Module  
Radio  
Right Side Object Detection Control Module  
Telematics Communication Interface Version 10  
Telematics Communication Interface Version 8  
Telematics Communication Interface Version 9  
Vehicle Direction Camera Control Module

**R Product Line**

-Powertrain

3.6L LLT Engine Control Module  
3.6L LLT Transmission Control Module  
Chassis Control Module  
Rear Differential Clutch Control Module

-Chassis

Electronic Brake Control Module

-Body

Body Control Module Mechanical Liftgate  
Body Control Module Power Liftgate (TB5)  
Inflatable Restraint Sensing and Diagnostic Module  
Passenger Presence Module  
Instrument Cluster  
Head-Up Display Module  
Radio  
Rear Audio Control Module

Digital Radio Receiver Control Module  
Personal Audio Link Control Module  
Telematics Communication Interface Version 9  
Telematics Communication Interface Version 10  
HVAC Auto Control Dual Zone (CJ2)  
HVAC Manual Control Single Zone (C67)  
Driver Door Switch Panel Control Module  
Passenger Door Switch Panel Control Module  
Liftgate Control Module  
Seat Memory Control Module  
Front Seat Heating Control Module  
Right Side Object Detection Control Module  
Left Side Object Detection Control Module  
Remote Control Door Lock Receiver  
Parking Assist Control Module  
Frontview Camera Module  
Theft Deterrent Module

**V Product Line**

-Powertrain

3.6L LLT Engine Control Module  
3.6L LLT Transmission Control Module  
Chassis Control Module  
Rear Differential Clutch Control Module

-Chassis

Electronic Brake Control Module

-Body

Body Control Module Mechanical Liftgate  
Body Control Module Power Liftgate (TB5)  
Inflatable Restraint Sensing and Diagnostic Module  
Passenger Presence Module  
Instrument Cluster  
Head-Up Display Module  
Radio  
Rear Audio Control Module  
Digital Radio Receiver Control Module  
Personal Audio Link Control Module  
Telematics Communication Interface Version 9  
Telematics Communication Interface Version 10  
HVAC Auto Control Dual Zone (CJ2)  
HVAC Manual Control Single Zone (C67)  
Driver Door Switch Panel Control Module  
Passenger Door Switch Panel Control Module  
Liftgate Control Module  
Seat Memory Control Module  
Front Seat Heating Control Module  
Right Side Object Detection Control Module  
Left Side Object Detection Control Module  
Remote Control Door Lock Receiver  
Parking Assist Control Module  
Frontview Camera Module  
Theft Deterrent Module



**1 Product Line****-Powertrain**

4.3L LV1 Engine Control Module  
4.3L LV3 Engine Control Module  
4.3L LV3 Transmission Control Module  
5.3L L83 Engine Control Module  
5.3L L83 Transmission Control Module  
5.3L L83 Transmission Control Module 6 Speed  
5.3L LC9 Engine Control Module  
5.3L LC9 Transmission Control Module  
5.3L LMG Engine Control Module  
5.3L LMG Transmission Control Module  
6.0L L96 Engine Control Module  
6.0L L96 Transmission Control Module  
6.0L LC8 Engine Control Module  
6.0L LC8 Fuel Injector Control Module  
6.0L LC8 Transmission Control Module  
6.2L L86 Engine Control Module  
6.2L L86 Transmission Control Module  
6.2L L86 Transmission Control Module 6 Speed  
6.2L L86 Transmission Control Module 8 Speed  
6.2L L94 Engine Control Module  
6.2L L94 Transmission Control Module  
6.6L LML Engine Control Module  
6.6L LML Glow Plug Control Module  
6.6L LML Power Take-Off Control Module  
6.6L LML Transmission Control Module My 2015 (WMF)  
6.6L LML Transmission Control Module My 2015.5 (AVF)  
Auxiliary Transmission Fluid Pump  
Chassis Control Version Active Grille Air Shutter  
Chassis Control Version Fuel Pump  
Chassis Control Version Fuel Pump and Trailer Brake Control  
Chassis Control Version Trailer Brake Control  
Chassis Control Version Trailer Brake Control and Automatic Level Control  
Drive Motor Control Module 1  
Drive Motor Control Module 2  
Transfer Case Control Module  
Transfer Case Version Single Speed Switch Activated (NP0)  
Transfer Case Version Two Speed Electric Shift (NQF)  
Transfer Case Version Two Speed Manual Shift (NQG)  
Transfer Case Version Two Speed Switch Activated (NQH)  
Transfer Case Version Two Wheel Drive

**-Chassis**

Electronic Brake Control Module  
Parking Brake Control Module  
Power Steering Control Module  
Steering Wheel Angle Sensor Module  
Trailer Brake Control Module  
Suspension Control Module  
Distance Sensing Cruise Control Module

**Multi-Axis Acceleration Sensor Module****-Body**

Amplifier  
Assist Step Control Module  
Auxiliary Body Control Module  
Base Radio  
Battery Energy Control Module  
Body Control Module  
Digital Radio Receiver Control Module  
Driver Door Switch Panel Control Module  
Frontview Camera Module  
Human Machine Interface Control Module  
HVAC Auto Control Dual Zone (CJ2)  
HVAC Control  
HVAC Manual Control Dual Zone (CJ3)  
HVAC Manual Control Heater Only (C42)  
HVAC Manual Control Single Zone (C67)  
Inflatable Restraint Sensing and Diagnostic Module  
Instrument Cluster  
Keyless Entry Control Module  
Left Side Object Detection Control Module  
Liftgate Control Module  
Media Disc Player  
Navigation Radio  
Parking Assist Control Module  
Passenger Door Switch Panel Control Module  
Passenger Presence Module  
Personal Audio Link Control Module  
Radio  
Radio Control  
Rear Audio Control Module  
Rear Seat Heating Control Module  
Remote Control Door Lock Receiver  
Right Side Object Detection Control Module  
Seat Memory Control Module  
Steering Column Lock Control Module  
Telematics Communication Interface Control Module Version 10  
Telematics Communication Interface Control Module Version 9  
Telematics Communication Interface Control Module Version 9.6  
Telematics Communication Interface Control Module Version 9.7  
Theft Deterrent Module  
Uplevel Radio

**2 Product Line****-Powertrain**

4.3L LV1 Engine Control Module  
4.3L LV3 Engine Control Module  
4.3L LV3 Transmission Control Module  
5.3L L83 Engine Control Module  
5.3L L83 Transmission Control Module

5.3L L83 Transmission Control Module 6 Speed  
5.3L LC9 Engine Control Module  
5.3L LC9 Transmission Control Module  
5.3L LMG Engine Control Module  
5.3L LMG Transmission Control Module  
6.0L L96 Engine Control Module  
6.0L L96 Transmission Control Module  
6.0L LC8 Engine Control Module  
6.0L LC8 Fuel Injector Control Module  
6.0L LC8 Transmission Control Module  
6.2L L86 Engine Control Module  
6.2L L86 Transmission Control Module  
6.2L L86 Transmission Control Module 6 Speed  
6.2L L86 Transmission Control Module 8 Speed  
6.2L L94 Engine Control Module  
6.2L L94 Transmission Control Module  
6.6L LML Engine Control Module  
6.6L LML Glow Plug Control Module  
6.6L LML Power Take-Off Control Module  
6.6L LML Transmission Control Module My 2015 (WMF)  
6.6L LML Transmission Control Module My 2015.5 (AVF)  
Auxiliary Transmission Fluid Pump  
Chassis Control Version Active Grille Air Shutter  
Chassis Control Version Fuel Pump  
Chassis Control Version Fuel Pump and Trailer Brake Control  
Chassis Control Version Trailer Brake Control  
Chassis Control Version Trailer Brake Control and Automatic Level Control  
Drive Motor Control Module 1  
Drive Motor Control Module 2  
Transfer Case Control Module  
Transfer Case Version Single Speed Switch Activated (NP0)  
Transfer Case Version Two Speed Electric Shift (NQF)  
Transfer Case Version Two Speed Manual Shift (NQG)  
Transfer Case Version Two Speed Switch Activated (NQH)  
Transfer Case Version Two Wheel Drive

**-Chassis**

Electronic Brake Control Module  
Parking Brake Control Module  
Power Steering Control Module  
Steering Wheel Angle Sensor Module  
Trailer Brake Control Module  
Suspension Control Module  
Distance Sensing Cruise Control Module  
Multi-Axis Acceleration Sensor Module

**-Body**

Amplifier  
Assist Step Control Module  
Auxiliary Body Control Module  
Base Radio

Battery Energy Control Module  
Body Control Module  
Digital Radio Receiver Control Module  
Driver Door Switch Panel Control Module  
Frontview Camera Module  
Human Machine Interface Control Module  
HVAC Auto Control Dual Zone (CJ2)  
HVAC Control  
HVAC Manual Control Dual Zone (CJ3)  
HVAC Manual Control Heater Only (C42)  
HVAC Manual Control Single Zone (C67)  
Inflatable Restraint Sensing and Diagnostic Module  
Instrument Cluster  
Keyless Entry Control Module  
Left Side Object Detection Control Module  
Liftgate Control Module  
Media Disc Player  
Navigation Radio  
Parking Assist Control Module  
Passenger Door Switch Panel Control Module  
Passenger Presence Module  
Personal Audio Link Control Module  
Radio  
Radio Control  
Rear Audio Control Module  
Rear Seat Heating Control Module  
Remote Control Door Lock Receiver  
Right Side Object Detection Control Module  
Seat Memory Control Module  
Steering Column Lock Control Module  
Telematics Communication Interface Control Module Version 10  
Telematics Communication Interface Control Module Version 9  
Telematics Communication Interface Control Module Version 9.6  
Telematics Communication Interface Control Module Version 9.7  
Theft Deterrent Module  
Uplevel Radio

**5 Product Line****-Powertrain**

2.5L LCV Engine Control Module Automatic Transmission  
2.5L LCV Engine Control Module Manual Transmission  
2.5L LCV Transmission Control Module  
3.6L LFX Engine Control Module Automatic Transmission  
3.6L LFX Engine Control Module Manual Transmission  
3.6L LFX Transmission Control Module  
Chassis Control Module  
Transfer Case Control Module

**-Chassis**



Electronic Brake Control Module  
Power Steering Control Module

-Body  
Body Control Module  
Inflatable Restraint Sensing and Diagnostic Module  
Passenger Presence Module  
Radio  
Amplifier  
Human Machine Interface Control Module  
Telematics Communication Interface Control Module  
HVAC Control Module Auto Single (C68)  
HVAC Control Module Manual Single (C67)  
Parking Assist Control Module  
Frontview Camera Module

### 6 Product Line

-Powertrain  
2.5L LCV Engine Control Module Automatic Transmission  
2.5L LCV Engine Control Module Manual Transmission  
2.5L LCV Transmission Control Module  
3.6L LFX Engine Control Module Automatic Transmission  
3.6L LFX Engine Control Module Manual Transmission  
3.6L LFX Transmission Control Module  
Chassis Control Module  
Transfer Case Control Module

-Chassis  
Electronic Brake Control Module  
Power Steering Control Module

-Body  
Body Control Module  
Inflatable Restraint Sensing and Diagnostic Module  
Passenger Presence Module  
Radio  
Amplifier  
Human Machine Interface Control Module  
Telematics Communication Interface Control Module  
HVAC Control Module Auto Single (C68)  
HVAC Control Module Manual Single (C67)  
Parking Assist Control Module  
Frontview Camera Module

### 7 Product Line

-Powertrain  
4.3L LU3 Engine Control Module  
4.3L LU3 Transmission Control Module  
4.8L L20 Engine Control Module  
4.8L L20 Transmission Control Module  
5.3L LMF Engine Control Module  
5.3L LMF Chassis Control Module  
5.3L LMF Transmission Control Module

6.0L L96 Engine Control Module  
6.0L L96 Transmission Control Module  
6.0L LC8 Engine Control Module  
6.0L LC8 Transmission Control Module  
6.6L LGH Engine Control Module  
6.6L LGH Glow Plug Control Module  
6.6L LGH Transmission Control Module

-Chassis  
Electronic Brake Control Module

-Body  
Body Control Module  
Inflatable Restraint Sensing and Diagnostic Module  
Passenger Presence Module  
Rollover Sensor Module  
Instrument Cluster  
Chime Alarm Control Module  
Base Radio  
Navigation Radio  
Uplevel Radio  
Digital Radio Receiver Control Module  
Telematics Communication Interface Version 9  
Telematics Communication Interface Version 10  
Auxiliary Heater Control Module  
Remote Control Door Lock Receiver  
Parking Assist Control Module  
Theft Deterrent Module

### 8 Product Line

-Powertrain  
4.3L LU3 Engine Control Module  
4.3L LU3 Transmission Control Module  
4.8L L20 Engine Control Module  
4.8L L20 Transmission Control Module  
5.3L LMF Engine Control Module  
5.3L LMF Chassis Control Module  
5.3L LMF Transmission Control Module  
6.0L L96 Engine Control Module  
6.0L L96 Transmission Control Module  
6.0L LC8 Engine Control Module  
6.0L LC8 Transmission Control Module  
6.6L LGH Engine Control Module  
6.6L LGH Glow Plug Control Module  
6.6L LGH Transmission Control Module

-Chassis  
Electronic Brake Control Module

-Body  
Body Control Module  
Inflatable Restraint Sensing and Diagnostic Module  
Passenger Presence Module  
Rollover Sensor Module  
Instrument Cluster

Chime Alarm Control Module  
 Base Radio  
 Navigation Radio  
 Uplevel Radio  
 Digital Radio Receiver Control Module  
 Telematics Communication Interface Version 9  
 Telematics Communication Interface Version 10  
 Auxiliary Heater Control Module  
 Remote Control Door Lock Receiver  
 Parking Assist Control Module  
 Theft Deterrent Module

- APIM(Accessory Protocol Interface Module)
- BCM(Body Control Module)
- BECM(Battery Energy Control Module)
- C-CM(Cruise Control Module)
- DACM-C(Digital Audio Control Module C)
- DCDC(DC to DC Converter Control Module)
- DDM(Driver's Door Module)
- DSM(Driver's Seat Module)
- DSP(Digital Signal Processing Module)
- FCDIM(Front Control/Display Interface Module)
- FCIM(Front Controls Interface Module)
- GFM(Generic Function Module)
- GPSM(Global Positioning System Module)
- GWM(Gateway Module A)
- HSWM(Heated Steering Wheel Module)
- HUD(Head Up Display)
- IPC(Instrument Panel Control Module)
- IPM-A(Image Processing Module A)
- OCSM(Occupant Classification System Module)
- PAM(Parking Aid Module)
- PDM(Passenger's Door Module)
- PSCM(Power Steering Control Module)
- RACM(Rear Audio Control Module)
- RCM(Restraint Control Module)
- RTM(Radio Transceiver Module)
- SCCM(Steering Column Control Module)
- SCM-E(Seat Control Module E)
- SOD-L(Side Obstacle Detection Control Module Left)
- SOD-R(Side Obstacle Detection Control Module Right)
- SOBDM-C(Secondary OBD Control Module C)
- SOBDM(Secondary OBD Control Module A)
- TCU(Telematic Control Unit Module)

## FORD USA

### Vehicle Information 2016 MY List Added

#### FORD EDGE 3.7L TiVCT Vehicle Added

- PCM(PowerTrain Control Module)
- ABS(Anti-Lock Brake System)
- ACM(Audio Control Module)
- APIM(Accessory Protocol Interface Module)
- BCM(Body Control Module)
- C-CM(Cruise Control Module)
- DCSM(Driver-Dual Climate Control Seat Module)
- DSM(Driver's Seat Module)
- DSP(Digital Signal Processing Module)
- FCIM(Front Controls Interface Module)
- FCDIM(Front Control/Display Interface Module)
- FLM(Front Lighting Control Module)
- GPSM(Global Positioning System Module)
- HUD(Head Up Display)
- HVAC(Heating Ventilation Air Conditioning)
- IPC(Instrument Panel Control Module)
- LTM(Liftgate/Trunk Module)
- OCSM(Occupant Classification System Module)
- PAM(Parking Aid Module)
- RCM(Restraint Control Module)
- RFA(Remote Function Actuator)
- RLCM-A(Rear Lighting Control Module A)
- TPM(Tire Pressure Monitor)
- SCCM(Steering Column Control Module)
- SOD-L(Side Obstacle Detection Control Module Left)
- SOD-R(Side Obstacle Detection Control Module Right)
- TBM(Tracking And Blocking Module)

#### FORD Fusion 2.0L Plug-in Hybrid Electric Vehicle Added

- PCM(PowerTrain Control Module)
- ABS(Anti-Lock Brake System)
- ACCM(Air Conditioning Control Module)
- ACM(Audio Control Module)

#### FORD Ranger 3.0L FFV Vehicle Added

- PCM(Powertrain Control Module)
- ABS(Anti-Lock Brake System)
- GEM(Generic Electronic Module)
- PATS(Passive Anti Theft System)
- RAP(Remote Anti-Theft/Personality Module)
- RCM(Restraint Control Module)

#### FORD Transit 3.7L TiVCT Vehicle Added

- PCM(PowerTrain Control Module)
- ABS(Anti-Lock Brake System)
- ACM(Audio Control Module)
- APIM(Accessory Protocol Control Module)
- BCM(Body Control Module)
- FCDIM(Front Control/Display Interface Module)
- FCIM(Front Controls Interface Module)
- GPSM(Global Positioning System Module)
- IPC(Instrument Panel Control Module)
- IPM-A(Image Processing Module A)
- IPM-B(Image Processing Module B)
- PAM(Park Aid Module)

For more information, please email [sales@e-zds.com](mailto:sales@e-zds.com), or call +82-70-7733-7811 or 7775

- RCM(Restraint Control Module)
- SASM(Steering Angle Sensor Module)
- TBC(Trailer Brake Control Module)
- TRM(Trailer Module)

**CHRYSLER/JEEP/DODGE**

## PCM

**New Type added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU info

## TCM

**New Type added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU info

## ABS

**New Type added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU info

## ORC

**New Type added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU info

## CGW

**New Type added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU info

## WCM

**New Type added**

- Basic Function
- DTC analysis
- Data analysis

## Actuation Test

ECU info

## CCN

**New Type added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU info

## AMP

**New Type added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU info

## FDCM/AWD

**New Type added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU info

## SAS

**New Type added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU info

## HVAC

**New Type added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU info

## MSMD

**New Type added**

- Basic Function
- DTC analysis
- Data analysis
- Actuation Test
- ECU info

## RADIO

**New Type added**

- Basic Function

DTC analysis  
Data analysis  
Actuation Test  
ECU info

**HFM****New Type added**

- Basic Function  
DTC analysis  
Data analysis  
Actuation Test  
ECU info

**EOM****New Type added**

- Basic Function  
DTC analysis  
Data analysis  
Actuation Test  
ECU info

**2015& 2016 Model Year and System added****ADCM (Adaptive Damper Control Module)**

- Basic Function  
DTC Analysis  
ECU Info

**AFLS (Adaptive Front Light System)**

- Basic Function  
DTC Analysis  
ECU Info

**BCM (Body Control Module)**

- Basic Function  
DTC Analysis  
ECU Info

**AFLS (Adaptive Front Light System)**

- Basic Function  
DTC Analysis  
ECU Info

**EDM (Electronic Damper Module)**

- Basic Function  
DTC Analysis  
ECU Info

**EPS (Electric Power Steering)**

- Basic Function  
DTC Analysis  
ECU Info

**ICS (Integrated Center Stack)**

- Basic Function  
DTC Analysis  
ECU Info

**IPC (Instrument Panel Cluster)**

- Basic Function  
DTC Analysis  
ECU Info

**LBSS (Left Blind Spot Sensor)**

- Basic Function  
DTC Analysis  
ECU Info

**RBSS (Right Blind Spot Sensor)**

- Basic Function  
DTC Analysis  
ECU Info

**RFH (Radio Frequency Hub)**

- Basic Function  
DTC Analysis  
ECU Info

**TGW (Telematics Gateway)**

- Basic Function  
DTC Analysis  
ECU Info

**Feedback**

Feedback received on 300 ,Grand Cherokee & Nitro  
Actuator Function added  
Vin writing Function added